

3DPIXA | 3D-Viewer Manual




Table of Contents

1	About Chromasens	4
1.1	Contact Information	4
1.2	Support	4
2	General Information	5
2.1	Software Requirements	5
2.2	Hardware Requirements	5
2.3	Compatible GPU	5
2.4	Recommended System	6
3	Getting started	7
3.1	Acquire a Sharp and Well Illuminated Image	7
3.2	Using the Viewer	7
4	Installing the 3D-Viewer	9
5	CS-3D-Viewer	10
5.1	Online Mode and Offline Mode	10
5.2	Image Formats	10
5.2.1	Raw Images	10
5.2.2	Output Images	10
5.3	Export Point Cloud as Other Formats	12
5.4	Display Modes	12
6	Using the Viewer	13
6.1	Opening 3D-Viewer	13
6.2	Loading and Saving a Configuration File	13
6.2.1	Loading a Configuration from File	13
6.2.2	Loading a Configuration from Camera	14
6.2.3	Saving a Configuration to File	16
6.2.4	Saving a Configuration File to the Camera	17
6.3	Loading (and Calculate) Raw Images	18
6.4	Load Mask Image (Optional)	19
6.5	Adjust Configuration Parameters	20
6.5.1	Height Range Limit	21
6.5.2	Height Range Wizard	23
6.5.3	General Parameters	24
6.5.4	Parameter of Semi Global Matching	24
6.5.5	Refinement Parameters of Block Matching	26
6.5.6	Visualization Parameters	28
6.5.7	Advanced Parameters	30
6.5.8	Camera Information	34
6.5.9	Automatically Check for Updates	35
6.6	Performance Measurement Tool	35

6.7	Operating the 3D-Viewer - Mouse and Keyboard Controls	36
6.7.1	3D Model	36
6.7.2	Height Map Image / Rectified Image	37
6.7.3	Pseudo-color Image	37
6.8	View Images in 3D-Viewer	37
6.8.1	Zoom ROI	37
6.8.2	Scroll within a Zoomed ROI	37
6.8.3	Reset ROI	38
6.8.4	Reset View of 3D model	38
6.9	Calculating 3D-Data	39
6.10	Loading and Saving Image Data Package	39
6.10.1	Saving Calculated Image-Data Package	39
6.10.2	Loading Precomputed Image-Data Package:	40
6.11	Export Point Cloud	41
6.11.1	Export Point Cloud as CSV-File	41
6.11.2	Export Point Cloud ROI as STL File	42
6.11.3	Export Point Cloud as VRML File	43
6.12	View ROI Info / Pixel Info	45
6.13	Other Functions	46
6.13.1	Other Menu Bar Functions	46
6.13.2	Sample Images and Sample Precomputed Data	46
6.13.3	Verify Calibration	47
6.13.4	Adjust Pseudo-color Map	49
6.13.5	Comparison of Two Areas	50
6.13.6	Generate System Information Report	51
6.13.7	License Information	52
6.13.8	Check for Updates	52
7	Advanced	54
7.1	Command-Line Parameters	54
7.1.1	General Parameters	54
7.1.2	Calculation Parameters	54
7.2	Configuration File Properties	55

1 About Chromasens

The name of our company, Chromasens, is a combination of 'Chroma' which means color, and 'Sens' which stands for sensor technology.

Chromasens designs, develops and produces high-quality and user-friendly products:

- Color line scan cameras
- 3D stereo line scan cameras
- Multi-spectral line scan cameras
- Camera systems
- Camera illumination systems
- Image acquisition systems
- Image processing solutions

Today, Chromasens GmbH is experiencing steady growth and is continually penetrating new sales markets around the globe. The company's technologies are used, for example, in products and for applications such as book and document scanners, sorting systems and inspection systems for quality assurance monitoring.

Customers from all over the world of a wide range of industrial sectors have placed their trust in the experience of Chromasens in the field of industrial image processing.

1.1 Contact Information

Chromasens GmbH

Max-Stromeyer-Str. 116

78467 Konstanz

Germany

Phone: +49 (0) 7531 / 876-0

Fax: +49 (0) 7531 / 876-303

Email: info@chromasens.de

1.2 Support

Chromasens GmbH

Max-Stromeyer-Str. 116

78467 Konstanz

Germany

Telephone: +49 (0) 7531 / 876-500

Fax: +49 (0) 7531 / 876-303

Email: support@chromasens.de

Visit our website at <http://www.chromasens.de> for detailed information on our company and products.

2 General Information

The Chromasens CS-3D-Viewer is a C# program that uses the CS-3D-API to calculate 3D information from the captured image(s). The CS-3D-API calculates a rectified RGB/BGR/gray-image, a 16-bit height map image and optionally a point cloud of the corresponding 3D model.

The Chromasens CS-3D-API and the Chromasens CS-3D-Viewer use the OpenCV library (which can be downloaded from <https://opencv.org>) for image processing. The license of the OpenCV library is included in the ".../Chromasens/3D/docs"-folder.

2.1 Software Requirements

- System
 - Windows 7, 8.1, 10 64-bit
- NVidia Driver Version 441.87 or newer
- Software protection dongle drivers
- For sample code only:
 - Development Environment
 - Microsoft Visual Studios 2010
 - MFC
 - OpenCV – Library v2.4

2.2 Hardware Requirements

- CUDA 3.0 capable GPU hardware with at least 3 GB RAM (see chapter [2.3](#))
- Quad Core i7 > 2.4 GHz
- RAM >= 16 GB
- Power-supply with enough power for the GPU(s)
- Software protection dongle

2.3 Compatible GPU

In general, every 3.0 CUDA capable GPU can be used. The following GPUs were tested for their compatibility:

Not compatible:

- NVidia GTX 285
- NVidia GTX 480
- NVidia GTX 580

Compatibility tested:

- NVidia GTX 680
- NVidia GTX 770
- NVidia GTX 780 TI
- NVidia GTX 980
- NVidia GTX 980 TI
- NVidia GTX Titan

- NVidia GTX 1060
- NVidia GTX 1080
- NVidia RTX 2070

2.4 Recommended System

- Software
 - Windows 10 x64

- Hardware
 - NVidia GTX Card with 4 GB RAM
 - Intel i7 3.2 GHz
 - 16 GB RAM
 - Software protection dongle
 - Chromasens 3DPIXA stereo camera system

3 Getting started

3.1 Acquire a Sharp and Well Illuminated Image

Firstly, you need to acquire a good image which can be used for the 3D-calculation. This may take up most of your time of 3D imaging. Use the Viewer only, if you have made sure, your image is sharp and well illuminated.

Follow the instructions below:

- Setup your 3DPIXA to the correct operating condition (refer to the 3DPIXA-Getting Started).
- If you take care of the following issues, the 3D calculation accuracy can be increased:
 - The image should be sharp. Please place the object in focus and check the pixels.
 - Example of a blurred and a sharp image



- The image should have as less shadow and as less glossy areas as possible. Please pay attention to the brightness of the illumination.

After having the correct camera setting, raw image(s) can be acquired for 3D calculation. The acquisition can be done for instance by using the program shipped with the frame grabber you are using.

Please make sure your raw image(s) have the correct format and size (chapter 5.2.1).

*You may use sample images provided to get familiar with the 3D-Viewer (chapter 6.13.2).

3.2 Using the Viewer

After acquiring a sharp and well illuminated raw image (chapter 3.1), please continue with the following steps:

- Check the system requirements.
- Install the CS-3D software (chapter 4)
- Plug the USB dongle into a USB-slot of your computer.
- Launch the 3D-Viewer
- Load the correct configuration file (chapter 6.2).
- Load and calculate your raw image(s) (chapter 6.3).

When the calculation completes, you will get the preliminary 3D calculation results.

- Adjust the system parameters (chapter 6.5) to obtain the best 3D images according to your needs.
 - The object height profile is calculated and shown in the height map image based on your configured system parameters.


Congratulations, you have just created a 3D image with highly precise height calculation with your 3DPIXA system.

*Furthermore, you may export the calculated 3D images and load them into the viewer in another time for instance for the purpose of demonstration (chapter [6.10](#)).

4 Installing the 3D-Viewer

For operating the 3D-Viewer, please make sure you have installed the current NVidia driver according to the defined system requirements.

Double click the “cs-3d-setup-vX.XX.exe” icon and choose the installation language.



cs-3d-setup-vX.XX.exe

From cs-3d-setup-v2.3e (and newer), the installer will also install Chromasens-Software-Manager together with the 3D-Viewer. This enables the 3D-Viewer to check for updates and download the newest version automatically, and also enables to keep other software products of Chromasens up to date.

Setup



The Chromasens-Software-Manager provides the update functionality for all the software products from Chromasens GmbH. It will be installed additionally to the CS-3D-Viewer.

OK


Follow the setup wizard to install the 3DPIXA-software package after installing Chromasens-Software-Manager. You may select the desired directory in which the 3DPIXA-software package should be installed. You may also choose which components of the 3DPIXA-software package you would like to install.

The software package includes the following:

- CS-3D-API
 - USB-Dongle driver
 - DLLs
 - Header files
 - C++, C# and HALCON Examples
- 3D-Viewer
- Example images
- Documentation and Manuals
- HALCON Extension 12, 13 or 18.11
 - Please choose the corresponding extension version during the installation. You can later change the version by reinstallation.

5 CS-3D-Viewer

The Chromasens 3D-Viewer can help you to evaluate your images acquired with the 3DPIXA.



5.1 Online Mode and Offline Mode

Online mode:

3D-data can be calculated based on the system parameters (chapter 6.5). A direct visual feedback is obtained after the calculation of the images.

A valid license (USB dongle) and a CUDA 3.0 enabled GPU are required to use the 3D-Viewer in Online mode.

Offline mode:

In offline mode, raw images cannot be loaded into the 3D-Viewer and 3D data cannot be calculated. You may load pre-computed data into the 3D-Viewer (chapter 6.10.2) in order to show the pre-computed 3D-data for the purpose of demonstration.

5.2 Image Formats

5.2.1 Raw Images

Image requirements:

- 8 bit, 24 bit and 32 bit images - png, bmp, gif format
- Image height: dependent of the available amount of RAM of the PC and the GPU. Calculation of images with larger image height results a larger RAM usage
- Image width: depends on the camera configuration and calibration
- Amount of raw images needed for 3D calculation
 - 1 raw image for the 3DPIXA - compact housing
 - 2 raw images for the 3DPIXA - dual housing

Please refer to chapter 6.3 for how to load raw image(s) into the viewer.

Raw images may be acquired by a frame grabber specific program.

5.2.2 Output Images

The 3D-Viewer calculates the 3D-data and outputs the following images if the corresponding options are enabled in configuration:

- Rectified image (24-bit png format)

The rectified image is the corrected image based on the raw images. It is corrected so the height map image perfectly fits on the rectified image. Also the distortion is removed.

- Height map image (16-bit gray-value tiff format)

The height map image includes the height information of the scanned object. Pixels with larger grayscale values in the height map image are higher than those with smaller values. The `grayToMm()` function that is documented in the CS-3D-API manual can be used to convert the pixel values to the height in mm.

The height map image is calculated with subpixel accuracy and is scaled to 16-bit value range within the selected height range (from lower height range limit to upper height range limit). Zero value indicates that no height information is present (chapter 6.5.1).

- Confidence map image (32-bit gray-value dat format)

The output of confidence map is optional. By default the confidence map won't be calculated and displayed. To activate the confidence map, the parameter `doCalcConfMap` has to be set to 1 in the configuration file, or the option "Calculate Confidence Map" in the tab page "Advanced Parameters" of calculation options has to be enabled. Confidence map provides a measure of the likelihood at each pixel position of the height calculation to be correct. Larger value (brighter area) in the confidence map indicates that the corresponding height calculation in the height map and point cloud is more confident, and vice versa.

- 3D-Point cloud (Chromasens specific cs3d format)

The 3D-Point cloud consists of a binary list of points with X, Y and Z coordinates. The X, Y and Z coordinates of all points are stored in a 1-D float array with one float per coordinate. The order of the coordinates is $X_0Y_0Z_0X_1Y_1Z_1X_2Y_2Z_2X_3Y_3Z_3\dots$. There is not a delimiter between the points and between the coordinates. The unit is millimeter.




Figure: the coordinate system of a 3d point cloud from Chromasens

The diagram above shows the point cloud coordinate system. X axis corresponds to point position in mm along sensor direction, y axis corresponds to point position in mm in scanning direction, and z axis corresponds to distance in mm from object surface to the free working distance plane. The origin (0, 0, 0) is placed in the middle between both lenses in the free working distance to the camera. The points in the left part of the image have negative X coordinates, and in the right part they have positive values. In the upper part they have positive Y coordinates and in the lower part they have negative ones. The Z coordinates further away than the free working distance from the camera are negative, and the ones closer are positive.

5.3 Export Point Cloud as Other Formats

You may export the 3D-point cloud information and the height map image as csv-file (e.g. for importing into Excel). Please refer to chapter [6.11.1](#) for how to export these information.

Furthermore, the 3D point cloud can also be exported as STL file (chapter [6.11.2](#)) or VRML file (chapter [6.11.3](#)), which can be viewed or processed in other 3D tools.

5.4 Display Modes

The 3D-Viewer offers five display options:

- **3D Model:** A plot showing the height profile of the object. 3D-Point cloud can be shown in this plot.
- **Height Map Image:** An intensity image showing the calculated 3D height profile. Brighter areas are higher than darker areas (see chapter [6.5.1](#) for further information). To display these gray values, they are reduced to 256 gray levels.
- **Rectified Image(A):** The corrected image from master camera which fits to the height map image.
- **Rectified Image(B):** The corrected image from slave camera.
- **Confidence Map:** By default the confidence map won't be calculated and displayed. To activate the confidence map, the parameter doCalcConfMap has to be set to 1 in the configuration file or the option "Calculate Confidence Map" in the tab page "Advanced Parameters" from the menu "Calculation" → "Options" has to be enabled
- **Raw Image:** The acquired image without processing.

Please refer to chapter [6.6](#) to see how to operate the 3D-Viewer in the different displays.

On the left side of the 3D-Viewer, the following information can be found:

- Height map image:
 - 16-bit intensity values are displayed (0-65535).
 - The pixel value can be converted to the distance to the camera.
 - If a pseudo-color ROI (region of interest) is selected, then the relative height difference between the current point and the mean height of the pseudo-color ROI is displayed.
- Rectified image: The R, G and B intensity values are displayed (8 bit: 0-255).
- ROI information (chapter [6.12](#))


6 Using the Viewer

6.1 Opening 3D-Viewer

The 3D-Viewer can be used in Online and Offline mode (chapter 5.1).

A valid license (USB dongle) and a CUDA 3.0 enabled GPU with current driver are required to use the 3D-Viewer in Online mode.

Double click the “CS-3D-Viewer” icon to open the 3D-Viewer.




Note: 3D-data (including 3D height map image) cannot be calculated in offline mode. Pre-computed data can be still loaded into the 3D-Viewer and the 3D-data can be shown. This can be done for demonstrations purposes for example.

6.2 Loading and Saving a Configuration File

6.2.1 Loading a Configuration from File


There are two options to load a configuration from file.

Option 1: Click the menu bar “File”, then click “Load config file” and choose “from file”




After selecting a configuration file in the following window and clicking the button “open”, the file will be loaded and applied.

Option 2: On the menu bar, click “Calculation” and select “Options” to open the configuration window.



In the configuration window, click “Settings” on the menu bar, select “Load config” and then “from file” to load the correct configuration file to the 3D-Viewer.



Select the configuration file “config.ini” or a previous saved “xxx_cfg.ini”, then click the “Apply” button of the configuration window


If an error occurs when loading the configuration file, please refer to chapter 7.2 for possible solutions. Or some parameters (chapter 6.5) are not set correctly in the given configuration file.

First time loading the configuration file:


The configuration file can be found in the folder “CalibrationFile” of the USB stick provided. Please copy and paste both files “config.ini” and “calibration.ini” to a desired folder before loading the configuration file.


6.2.2 Loading a Configuration from Camera

A configuration can also be loaded from the camera. Clicking the menu bar “File” → “Load config” → “from camera”,




Or clicking the menu bar “Calculation” → “Options” → “Settings” → “Load” → “from camera”,





By starting to load configuration from camera, all the currently available ports are listed. You can choose one port, and click the button “LoadConfig from Camera”, to load the configuration from the camera from the chosen port.

If you are not sure, which cameras are currently connected to which port, you can click the button “Search connected Cameras” to detect them. The detection will last for a while. After that, the connected cameras will be shown. This helps to find a connected camera more easily. By default, the search option “Camera Link” is activated. If you want to detect additional cameras, which are connected with RS232, you can also enable the search option “RS232”.



NOTE Please pay attention that all the other tools which establish camera connections, such as Camera Setup Tool (CST), have to be closed before running the detection here. Otherwise, the camera cannot be detected because the connection is already in use.


After executing “Load Config from Camera”, the program will inform you the result. It can be “successful” or a code which indicates the error. Only newer 3DPIX A cameras have the configuration and the calibration stored within the camera.

6.2.3 Saving a Configuration to File

After modifying the system parameters (chapter 6.5), you may save the current configuration by opening menu bar “Calculation” -> “Options” and then choosing “Save config” → “to file” under “Settings”.

There are three possibilities to save the configuration locally on computer.


- “to current config file”: The config file, which is loaded, will be overwritten.
- “to default config file on this PC”: A configuration file and a calibration file are overwritten in the directory: C:\Users\Public\Documents\Chromasens\3D\viewer settings. At the next start of 3D-Viewer, the default config will be loaded from there (chapter 7.2).
- “as...” the configuration and its corresponding calibration file can be saved anywhere else in a certain folder.



NOTE The configuration file accesses information stored in the calibration file “calibration.ini”. It is therefore important that the directory stated in the configuration file is correct. Please refer to chapter 7.2 for more information.

6.2.4 Saving a Configuration File to the Camera

Similar to Loading a configuration from the camera, you can also write the configuration into the camera. The saving process can be started by clicking menu bar “Calculation” → “Options” → “Settings” → “Save config” → “to camera”. The button “Save Config To Camera” executes the saving process and copy the current configuration into the camera, which is connected to the chosen port.



6.3 Loading (and Calculate) Raw Images

Please make sure you have loaded the correct configuration file before loading your raw image(s) (chapter 6.2).


On the menu bar, click “File”, point on “Load raw file(s)” then

For 3DPIXA - compact housing:

- click “Single raw image”
- load the raw image

For 3DPIXA - dual housing:

- click “Two raw images”
- load XXX_A.png/bmp/gif and XXX_B.png/bmp/gif subsequently




You may directly calculate the 3D height map based on the configuration file loaded. The 3D data then is directly calculated. Choose “Load and calculate” then

For 3DPIXA - compact housing:

- click “Single raw image”
- load the raw image

For 3DPIXA - dual housing:

- click “Two raw images”
- load XXX_A.png/bmp/gif and XXX_B.png/bmp/gif subsequently



Depending on the number of cameras in the current loaded config file, the appropriate option “Single raw iamges” or “Two raw images” can be selected and the other one will be deactivated accordingly.

NOTE The calculation of an image with a very large image height can result in a big consumption of CPU and GPU memory. In this case the user will receive a warning message about the possible memory shortage after loading a raw image. Then he can decide whether he wants to continue or cancel the calculation.


6.4 Load Mask Image (Optional)

In most cases, we calculated the height information of the whole image. But if we are only interested in certain areas on the image, then we can create a mask image, load it into the 3D-Viewer. If the mask is enabled, the calculation will only occur on the areas of the mask image, where the grayscale is not zero.

Attributes of a mask image:

- 1) Can be an RGB or grayscale image
- 2) Has exactly the same image size as the height map result.
- 3) If a mask image is enabled, black-areas (color value [0, 0, 0] of an RGB, or 0 of an grayscale) of the mask image will not be considered for the calculation. Only non-black areas have height information.

A mask image can only be loaded when the raw image is already loaded. To calculate the image with a mask, please click menu “File” → “Image Mask” → “Load Image Mask and Calculate” to choose a mask image from PC. Then mask image will be displayed in the tabpage “Mask Image”, and be used for the calculation



If the mask should be disabled for the next calculation, please click “Enable Mask” to uncheck it. To enable the mask, “Enable Mask” should be checked again.




Figure: image mask





Figure: height image with image mask

6.5 Adjust Configuration Parameters

After loading the calibration file and your acquired raw images, you may evaluate your images and re-calculate the 3D-data after adjusting the system configuration parameters.

On the menu bar, click “Calculation” and select “Options” to open the configuration window.







Figure: Configuration window

6.5.1 Height Range Limit



The height range indirectly defines the camera distance range which is applied to calculate your 3D data. The lower value of the selected height range (namely height range start) should correspond to the lowest point of your object and the upper value (namely height range end) to the highest point of your object. It is suggested to start with a big range, and then reduce to the smallest possible height range that includes the structures you would like to analyze. Height information between height range start and height range end is represented by 16-bit data, leading to a highly accurate 3D height calculation. It is also possible to use the “Height Range Wizard” to find the suitable upper and lower height range limit.




Figure: Height range limit


The height range can be set either with the option “Height Range” or “Distance to 0 Plane”

- Height Range [unit: pixel]: Each camera has its own free working distance, where the sharpest image of the scanned object should be normally acquired. The plane, on which the object has the free working distance to camera, is also called the 0 plane. The height range is based on this relative pixel shift of an image point between the left and right rectified image. The valid interval of this parameter depends on the height range defined in the calibration.
- Distance to 0 Plane [unit: mm]: Here you may change the height range in the unit mm according to this 0 plane. The both ranges can be converted into each other. The valid interval of this parameter depends on the height range which is described above. Additionally, the range of absolute distance to the camera in unit millimeter will be also shown below, which provides situationally an obvious impression of the used distance range in the reality.
- An object point at the 3DPIXA's working distance plane / zero-plane has a shift of zero pixel between the both images.
- An object point below the working distance plane (further from the camera) has a negative shift in pixel between both images / is in the negative part of the height range and has a negative distance to 0 plane.
- An object point above the working distance plane has a positive shift in pixel between both images / is in the positive part of the height range and has a positive distance to 0 plane.


The 16-bit height map image is scaled between the chosen height range start and height range end. The intensity value of the height map correlates to the height of the object. Pixel value 1 and 65535 of a height map correspond the given height range start and height range end. Value 0 indicates that the height information is not available. For conversion from the intensity values to height information in millimeter, please refer to the 3D-API manual.

6.5.2 Height Range Wizard

The choice of height range affects the height map result. The height range wizard can provide the preview of height map if the height range is changed. The wizard can be started by clicking the button “Height Range Wizard”, The configuration file and the raw images have to have been loaded already.




In upper area of the wizard, the user can adjust the lower height range limit (dStart) and upper height range limit (dEnd) by moving the scrollbars. The preview of rectified image and of height map will be changed accordingly.



If one area on the object is out of the height range, then this area will be displayed as black in height map preview, In preview of rectified image, this area will be marked as red (if it is above the upper height range limit) or green (if it is below the lower height range limit). So it is possible to adjust the height range to get an appropriate height map.

6.5.3 General Parameters



Configuration

Load/Save Settings ...

Calculation Parameters **Matching Method Parameters** Visualization Parameters Info

Matching Method

Use SGM (Semi Global Matching) Use Block Matching

General Parameters

Gray Value Range Min: 0 Max: 254

Used Color Channels: All

Parameters for SGM

Use Fixed Height Range 128 P1: 7 P2: 100

Refinement Parameters for Block Matching

Correlation Window Size: 15x15

Minimum Correlation Factor: 0,01

Left/Right Consistency: 10

Minimum Contrast: 0,01

6.5.3.1 Gray Value Range


This parameter specifies the minimum and the maximum pixel intensity value that are used for the 3D data calculation. Very dark and bright pixels of shadow and gloss areas outside the given gray value range are excluded for the calculation, because these points do not have enough contrast for correlation. The valid value of this parameter can be set to [0, 255].

6.5.3.2 Color Channels

You may choose to use all the color channels, or only one channel (blue, green or red) for calculating the 3D data.

6.5.4 Parameter of Semi Global Matching

There are two matching methods to calculate the height information. To change the parameters of semi global matching, please enable "Use SGM (Semi Global Matching)" in "Matching Method Parameters" first.



6.5.4.1 Fixed Height Range

Default value is unchecked, which means dynamic height range is used.


User can choose between fixed height range or flexible height range. With fixed height range, the maximum height search range is 128 pixels. If the input height range (dEnd-dStart) is larger than 128, dEnd is ignored. With flexible height range, any height range is accepted for calculation, and dStart and dEnd are used for calculating the height range.

6.5.4.2 P1 and P2

P1: constant penalty value for small disparity change (i.e. 1 pixel). Using a lower penalty for small changes permits an adaptation to slanted or curved surfaces. P1 is in range between 0 and 31. Default value is 7.

P2: constant penalty for all larger disparity changes (i.e. larger than 1 pixel). It preserves discontinuities. Discontinuities are often visible as intensity changes. It has always to be ensured that $p2 > p1$. p2 is in range between 0 and 127. Default value is 100.

6.5.5 Refinement Parameters of Block Matching



To change the refinement parameters of block matching, please enable “Use Block Matching” in “Matching Methode”. The refinement parameters and their influence will be introduced below.

6.5.5.1 Correlation Window Size



The size of the pattern window is adjustable by a parameter. The larger the window size, the better the stability and reliability of the correlation results. Furthermore, the height accuracy increases with window size. If you want to see fine details of the object, then we recommend smaller window sizes. As a trade-off, more unrelated points may be correlated, which will lead to false calculations




Figure:Influence of correlation window size

- The window size defines the size of the neighborhood area of the pixels that is used to find pixel correspondance from one image to another.
- A larger window is better for objects with less textures.
- A smaller window takes fine texture structures more into account, is however a bit more noise-sensitive .




Figure: Window size 3x3 sharper edges, but more points without information (“black holes”)





Figure: Window size 27x27, smooth edges, closed surface

6.5.5.2 Minimum Correlation Factor

The “Minimum Correlation Factor” can be set between 0.00 and 1.00.

- With small factors, weak correlating structures are accepted, and the accuracy may not be as high as with larger factors, but a closed height map can be generated.
- With large factors, only strong correlating structures are accepted, resulting in higher accuracy of the calculation, but areas with weak correlation under the given threshold will not be taken into account and have therefore no height information.

The higher the “Minimum Correlation Factor” is, the more confident a computed height is.



Left: Height image with a correlation factor 0.9. Right: with a correlation factor 0.3

6.5.5.3 Left/Right Consistency

The correlation is working in both ways. Points from the left image will be matched to the right image and points from the right image will be matched to the left image. So in total we have for one object (image) point two correlation results. The left/right consistency value specifies maximum accepted difference (in pixel unit) between left-right matching result and right-left matching result. A lower value leads to more reliable measurements. This parameter can be set between 0 and 100.

6.5.5.4 Minimum Contrast

With this function you can define the acceptable level of contrast for the 3D data calculation.

The numerical range is from 0.00 to 255.00. For example, 10.00 means you accept 3D calculation results with mean intensity difference larger than 10.00 between the pixels within the correlation window. In the resulting data the areas with a lower contrast than the minimum contrast are marked out. 0.00 means all contrast levels are used for the 3D data calculation. Using a very low contrast level may lead to not so accurate results in areas of less contrast.

6.5.6 Visualization Parameters

You can find these parameters by clicking the menu bar “Calculation” → “Options” → tab page “Visualization Parameters”


<p>Pseudo Color Map</p> <p>Mark out Outliers in Pseudo Color Map</p> <p>Valid Range Min: <input type="text" value="0,0"/> %</p> <p>Valid Range Max: <input type="text" value="100,0"/> %</p> <p><input type="checkbox"/> Use Correction Plane</p>	<p>3D Display</p> <p>Point Cloud Resolution: 1 / <input type="text" value="10"/></p> <p><input type="checkbox"/> Do Smoothing</p> <p><input type="checkbox"/> Display Absolute Coordinates</p> <p><input type="checkbox"/> Display without Axis</p>
--	--

6.5.6.1 Correction Plane


If your object is tilted, you may enable this function. By enabling this function, the viewer creates a virtual plane and calculates the 3D height of the object based on the created plane. This function is used for the pseudo-color image. The default value of this parameter is “disabled / not selected”.

6.5.6.2 Outlier Exclusion

With this setting, you may set the percentage of pixels to be marked as potential outliers. The valid range minimum can be set between 0.0% and 30.0% and the default value is 0.0%. The valid range maximum can be set between 70.0% and 100.0% and the default value is 100.0%. If we sort all the valid height values in a pseudo-color map from small to big and put them in a queue (assuming that there are N valid height values in this queue), then the smallest (N*minimum% points at beginning of the sorted queue) and the biggest height values (N*maximum% points at end of the sorted queue) will be marked as black in pseudo-color map. Other values in-between will be retained and displayed as normal. This could be used to mark out some noise areas such as peaks or valleys on a height map, because such areas



often have extremely high or low height values.



Left: retain 0.5% - 99.5%

Right: retain 3.0%-97.0%

6.5.6.3 Point Cloud Resolution

With this setting, you can set the sampling rate for the 3D-model computation and display. The default value is 1/10, which means 1 out of 10 points are selected to be computed and displayed. The finest resolution is achieved when the 3D resolution is set to 1/1, where every point is displayed in the 3D-model. However this could lead to a large amount of data to be displayed. So please be careful of the large data, when the resolution is going to be set to 1/1.





Figure: 3D resolution 1/10: Every 10 points are sampled




Figure: Point cloud resolution 1/2: Every two points are sampled

6.5.6.4 Smoothing

With this function enabled, the results of the 3D-calculation will be smoothed. This will make the results look nicer, but also increases the calculation time. The default value of this parameter is “disabled / not selected”.



Left: 3D model without smoothing



Right: 3D model with smoothing


6.5.6.5 Absolute Coordinates

When this option is enabled, the 3D-object is shown with absolute x and y coordinates (chapter 5.2.2). Otherwise, the origin coordinate (0, 0) is set to (xmin, ymin) of the object. The z coordinates are not affected in both situations.

Even by restarting the 3D-Viewer, almost all the parameters in tab page “Visualization Parameters” will use their previous settings. Please check these parameters if you want to change the visualization.

6.5.7 Advanced Parameters

The following parameters are listed in the tab page “Advanced Parameters”.



6.5.7.1 Calculate 3D Point Cloud

The default value of this parameter is “enabled / selected”. In a configuration file, this corresponds to `doCalc3DPoints=1` by default. This can be disabled if the 3D calculation or display is not necessary. (In current beta version, 3d point cloud calculation is not supported if semi global matching is enabled)

6.5.7.2 Calculate Height Map

The height map provides the height information in 16bit (and displays it as a 8 bit grayscale image in the viewer). The areas, which are closer to camera, have a larger height, and will be displayed as brighter regions on a height map. The areas which are further away to camera, have a lower smaller height, and will be displayed as darker regions. In a configuration file, this corresponds to `doCalcHeightImage=1` by default. If it is disabled, then the point cloud and confidence map, which are based on height map, will be disabled too. For general use of 3D-Viewer, it is strongly recommended to keep height map and rectified image enabled.

6.5.7.3 Calculate Rectified Image(A)

The rectified image provides a preprocessed image of camera A, in which the camera distortions are rectified. The default value of this parameter is “enabled / selected”. This corresponds to `doCalcRectifiedImage=1` by default in a configuration file. The rectified image will be used as a texture to render the point cloud, so if the calculation or display of point cloud is activated, then it is also recommended to enable rectified image,

6.5.7.4 Calculate Rectified Image(B)

The rectified image provides a preprocessed image of camera B, in which the camera distortions are rectified. The default value of this parameter is “disabled / unselected”. This corresponds to `doCalcRectifiedImageB =0` by default in a configuration file.


6.5.7.5 Calculate Confidence Map

The confidence map provides a visualization of reliability of the height information of each pixel. The brighter areas in a confidence map have a higher correlation value and thus the height information there is more confident. The default value of this parameter is “disabled /unselected”. In a configuration file, this corresponds to doCalcConfMap=0 by default. In order to calculate and display the confidence map, this option needs to be enabled / selected in the 3D-Viewer. (In current beta version, confidence map calculation is not supported if semi global matching is enabled)


6.5.7.6 Enable Central View

Since version v2.3 of 3D-Viewer, the user can enable or disable central view directly in the 3D-Viewer. The following diagram shows the difference of rectified result image with disabled/enabled central view feature. The default value of this parameter is „disabled“, and corresponds to enableCombinedView=0 in configuration file. This means, the generated rectified image and height image are based on the viewing angle of one camera, which leads to perspective distortion. If this option is enabled (which corresponds to enableCombinedView =1 in configuration file), then the viewing angle of both cameras will be considered and the perspective distortion will be corrected. This feature is only available for calibration version 2.1 or newer. (For calibration version, please refer to camera information in [6.5.8](#)) (In current beta version, central view calculation is not supported if semi global matching is enabled)

Without perspective correction / central view




With perspective correction / central view



6.5.7.7 Limit to High Accuracy Range

The default value of this parameter is “enabled”. In a configuration file, this corresponds to `enableHeightRangeLimit=1`.

There are two kinds of height range limits (chapter 6.5.1).



If this option is enabled: The height range limit which can be applied for very accurate measurements, will be used, If the chosen height range start and height range end are set within this limit, then a highly reliable calculation result can be expected.

If this option is disabled: A wider height range limit is allowed for the calculation. If the height range start and height range end are set within this limit, but outside the high accuracy range limit, which is mentioned above, then the calculation could be less accurate.


6.5.7.8 Scan Direction

The default value of scan direction is “Forward”, which means the objects are scanned forward in respect of the camera. The user has the possibility to change the scan direction to “backward” if the calibration of the camera is v2.0 or newer. This can be applied directly for objects which are scanned backwards.

The forward scan direction is defined as following:



Top view: 3DPIXA compact



Top view: 3DPIXA dual

NOTE This feature is only available for cameras with calibration file of version 2.0 or newer.

The option “Scan Direction” will be deactivated in 3D-Viewer for cameras which have an older version of calibration.


If the scan direction is changed to “Backward”, also the scan direction of the camera setting has to be adjusted using the CST-software or the CS-API.

6.5.7.9 Timeout

The timeout given in seconds limits the time available to calculate the 3D-data. A timeout can be hit if the image is very large or the used GPU has less computing power. In that case increasing the timeout is an option. The default value for timeout in Chromasens 3D-Viewer is 40 sec. The timeout can be set from 40 to 200.

6.5.8 Camera Information

In the tab page “Info”, the information of the camera will be shown.



Sensor: compact housing, or dual housing.

Image Height: the height of the image which is currently loaded. If no image is loaded, the height will be obtained from the configuration file.

Image Width: the width of the image.

Resolution x: the resolution in lateral direction.

Resolution y: the resolution in scan direction.

Serial Number: each camera has its own serial number for identification

Type: the product type, which the camera belongs to.

Calibration Version: The version of calibration.


Calibration Date: The date shows when the camera was originally calibrated.

6.5.9 Automatically Check for Updates


This option can be found in the tab page “Info”. Its default value is “enabled / selected”. If enabled, 3D-Viewer will check for updates from the server once per day. Similar to the manually check for update (6.13.8), the automatic check will be executed daily and inform the user, only if there is a newer version available. (Internet connection has to be available.)

6.6 Performance Measurement Tool

The 3D-Viewer has a built-in tool for performance measurements that can be accessed through the menu of the main window:



Like all 3D calculations it requires both a configuration and input image(s) for running the performance tests. The performance test will use the configuration and image data that was loaded for the previous calculation. In case no configuration or no image data has been loaded, this can be done directly from the “Performance Test” dialog by selecting the “Load Configuration...” (2) and “Load Image(s)...” (3) buttons. There is also an “Options...” (4) button that allows changing parts of the configuration and directly restart performance tests without closing the dialog.



A performance test should be executed with enough iterations (e.g. 25) which can be specified in the “Number of iterations” field (1). The test can be start from the “Run Performance Test” (5) button and canceled with the “Close” / “Cancel” (6) button at any time. A progress bar will be shown to indicate the progress and the results will be displayed in the text fields of the “Results” (7) section. The performance test result shows the throughput in lines per second.

6.7 Operating the 3D-Viewer - Mouse and Keyboard Controls

6.7.1 3D Model

Mouse controls:

- Rotation: Left mouse button pressed down
- Panning: Middle mouse button pressed down
- Zoom in and out: Scrolling the mouse wheel or right mouse button pressed down

Keyboard controls:

- Rotation around the X-axis: Insert / Delete
- Rotation around the Y-axis: Home / End
- Rotation around the Z-axis: Page up / Page down
- Panning: Cursor keys
- Zoom in and Zoom out: + / -
- Reset zoom and position: “R”
- Spread the height: Shift-key + Scrolling middle mouse wheel

To make small height differences better visible, the Z-value of the 3D points can be multiplied by a factor. This factor is increased / decreased by using the mouse wheel.

3D mouse controls:

Currently support is the 3D-Connexion SpaceNavigator

The movement of the object is very intuitiv, e.g. pull the button in your direction to zoom in at the object.

Reset zoom and position: Click the right-mouse button.

6.7.2 Height Map Image / Rectified Image

Mouse control:

- Show pseudo-color image: **Left mouse button** pressed down and drawing of a rectangle (chapter 6.7.3).
 - By showing an area in pseudo-color image, the 3D model also shows the pseudo-color image.
- Zoom in rectangle area: **Right mouse button** pressed down and drawing of a rectangle
- Reset image: **Middle mouse button** or keyboard “r”.

6.7.3 Pseudo-color Image

Press down the left mouse button in the rectified or the height map image and draw a rectangle to specify the rectangle for the pseudo-color image.

There are two types of pseudo-color image.

- **Default:**
The default pseudo-color image scales pseudo-color between the lower and the upper height range limit **within** the selected rectangle. The free working distance plane in the selection is displayed as 0 mm.
- **Correction plane (can be used, if your object is tilted to the 3DPIXA camera):**
A plane is fitted through all the height values. A scanned object which lies tilted to the 3DPIXA camera within the 3D space is then fitted to the new plane. The pseudo-color view shows the height values relatively to the new fitted plane. The height in mm is displayed relatively to that plane. The heights in the selection below the plan are displayed as negative values, the values above as positiv values.
Activate the correction plane via “Calculations→Options” and checking the “Use Correction Plane” check box at the “Configuration window”.

6.8 View Images in 3D-Viewer


The raw images, their height map image and rectified image can be viewed in CS3D-Viewer.

6.8.1 Zoom ROI

Press down the right mouse button and draw a rectangle to specify the rectangle for the region of interest of one image in CS3D-Viewer. If you are interested in a particular region of the image, you can zoom at it.

6.8.2 Scroll within a Zoomed ROI

If the image is zoomed to ROI, then the ROI can be scrolled horizontally and vertically with the scrollbars.



6.8.3 Reset ROI

Press “r” or the **middle mouse button** to reset the zoom of the height map image and the rectified image.

Please notice that the height map image, the rectified image and confidence map share the same ROI, but raw image A and raw image B have their own ROI.

Operation on	Zoom	Scroll	Reset
Height map image	ROI of rectified image, height map image and confidence map will be refreshed simultaneously.	ROI of rectified image, height map image and confidence map will be refreshed simultaneously.	ROI of rectified image, height map image and confidence map will be reset simultaneously.
Rectified image(A/B)			
Confidence map (if activated)			
Raw image A	Only its own ROI will be changed	Only its own ROI will be changed	Both raw image A and B will be reset
Raw image B	Only its own ROI will be changed	Only its own ROI will be changed	


6.8.4 Reset View of 3D model

If the 3D model was rotated or moved from its origin, you can click the middle mouse button or the “r” key on the keyboard to reset this view back to origin, but the already selected ROI in 3D model view won't be reset.

6.9 Calculating 3D-Data

Please make sure that you have your raw image(s) and corresponding configuration file loaded (chapter 6.2 and 6.3)

On the menu bar, click “Calculation” and select “Do 3D Calculation”




You may modify the system parameters before 3D-calculations. Please refer to chapter 6.5.

6.10 Loading and Saving Image Data Package


6.10.1 Saving Calculated Image-Data Package

On the menu bar, click “File” and select “Save calculated image-data package”.



6.10.1.1 Saving Components of Calculated Image-Data Package Separately

The following components will be saved in the chosen directory (XXX is the specified file-name) if *.cs3d format is chosen.




The newly saved configuration file “XXX_cfg.ini” accesses the information stored in the calibration file “calibration.ini” located in the same directory. It is therefore important that when changing the location of the configuration file, the calibration file has to be moved to the same locations as the configuration file.

Generated file in the data package	Filename	Format
Raw image(s)	Single camera system: XXX_AB.png Dual camera system: XXX_A.png, XXX_B.png	PNG, can be opened with standard image viewer tool

Mask image (if enabled)	XXX_Mask.png	PNG, can be opened with standard image viewer tool						
Height map image	XXX_height.tiff	TIFF (16 bit zip compressed TIFF), can be opened with standard image viewer tool.						
		Pixel(N)		Pixel(N+1)		...		
		unsigned short		unsigned short		...		
Rectified image(A)	XXX_tex.png	PNG, can be opened with any image viewer tool						
Rectified image(B)	XXX_texB.png							
3D point cloud	XXX_p3d.cs3d	CS3D (Each pixel is presented by x-, y- and z-coordinate. Data type: float), can be only displayed with CS-3D-Viewer.						
		Pixel(N)		Pixel(N+1)		...		
		x	y	z	x	y	z	
		float	float	float	float	float	float	...
Confidence map (if activated)	XXX_confmap.dat	DAT, can be only displayed with CS-3D-Viewer.						
		Pixel(N)		Pixel(N+1)		...		
		float		float		...		
Configuration file	XXX_cfg.ini	INI, can be opened with standard text editor tool						
Calibration file	calibration.ini	INI, can be opened with standard text editor tool						


6.10.1.2 Saving Components of Calculated Image-Data Package in one file

Different from above, if *.ccs3d is chosen as the save format, then all the components will be saved in one file, which can also be loaded into viewer later.




6.10.2 Loading Precomputed Image-Data Package:

User can load the image data which was saved with the “Save calculated image-data” function of the viewer before.



6.10.2.1 Loading Precomputed Image-Data Package from a Chromasens 3d File (*.cs3d)




Choose the XXX_p3d.cs3d file.

The files saved (chapter 6.10.1.1) must be located in the same folder as the XXX_p3d.cs3d file.

(XXX is the given file name.) By choosing a cs3d file from the file dialog, all the components which belongs to this 3d package can be located and then loaded. Because this method loads cs3d file, so the point cloud file must exist.

6.10.2.2 Loading Precomputed Image-Data Package from a Compressed File (*.ccs3d)

Another possibility is to load the whole 3d data package from a compressed file. This file can be generated from chapter 6.10.1.2, which contains all necessary components. They will be uncompressed and then displayed in 3D-viewer.




6.11 Export Point Cloud

6.11.1 Export Point Cloud as CSV-File

You may save a region of interest as a CSV-File. Press down the right mouse button and draw a rectangle of the ROI. If no ROI is drawn, the whole image is selected. On the menu bar, click "File", point on "Export" and select which file you would like to export.

- Export height map ROI as CSV:

You can save the chosen ROI as a csv-file that includes the height in mm for each pixel. The first row holds the X and Y position followed by the width and the height of the ROI. The data follows one row for each line of the ROI. Invalid points are saved as 0.




After saving the csv-file, you can open it (for example with Excel) to check the data of pixel value from the height map image.

	A	B	C	D	E	F	G
1	1534	1857	114	101			
2	150,4761	150,4792	150,4805	150,4834	150,4824	150,4838	150,48
3	150,4788	150,4797	150,4832	150,4817	150,4826	150,4824	150,48
4	150,4799	150,4833	150,4804	150,4853	150,4839	150,4816	150,48
5	150,4777	150,4812	150,4866	150,4805	150,4799	150,4818	150,48
6	150,4722	150,4764	150,4763	150,4737	150,4791	150,4751	150,47
7	150,4653	150,4684	150,4682	150,47	150,468	150,4669	150,46
8	150,4674	150,4694	150,4672	150,4594	150,4627	150,4669	150,47
9	150,471	150,4696	150,4537	150,4646	150,472	150,466	150,46
10	150,4645	150,4687	150,4701	150,4701	150,4706	150,4673	150,46
11	150,4677	150,4605	150,4695	150,4793	150,4659	150,4606	150,4
12	150,469	150,4724	150,47	150,4627	150,4635	150,4697	150,46

- Export 3D-point cloud ROI as CSV


You can save the X, Y and Z positions of an ROI of the point cloud to file. The first row holds the X and Y position followed by the width and the height of the ROI. Then each following row consists of the X, Y and Z coordinate of one point, which has valid height value. The coordinates of points with no height information won't be exported.




	A	B	C	D
1	1874	2172	41	58
2	-1,184566	-1,519676	-0,3524506	
3	-1,17433	-1,519768	-0,3526212	
4	-1,163985	-1,519864	-0,3522128	
5	-1,153658	-1,51996	-0,3518195	
6	-1,143248	-1,520058	-0,3510606	
7	-1,132919	-1,520154	-0,3506978	
8	-1,122728	-1,520244	-0,351158	
9	-1,112548	-1,520333	-0,3516943	

6.11.2 Export Point Cloud ROI as STL File

The x, y, z-coordinates of the whole point cloud, or part of the point cloud, can be exported as a STL (stereo lithography)-file, which can be opened in other tools for further processing.



If the point cloud data is available (either after 3d calculation or after loading a precomputed dataset), by clicking “File” → “Export” → “3D-point cloud as STL file”, the following option window will be shown.




You can set the upper left and bottom right corners to define a region by yourself, in which the data will be exported. The ROI size will be changed correspondingly depending on the coordinates. The default region is the predefined ROI (which is defined by dragging & clicking right mouse). Otherwise, the default region is the whole image size (width * height)

The sample distance defines the density of the sample points in the point cloud. By default it is set to 10, which means, every 10th point will be sampled in horizontal and vertical direction. If the sample distance is set to 1, then every point will be used which can cause a high memory and disk usage.


By clicking the button “Export” you can choose a file name where the result is saved to. If the checkbox “Compress STL in a zip file” is activated, a compressed zip file that includes the STL file will be generated.

6.11.3 Export Point Cloud as VRML File

Similar to export the point cloud data as a STL file, the point cloud can be also exported as a VRML (virtual reality model language)-file, together with its texture file (.PNG-file in this case) for further processing.



If the point cloud data is available (either after 3d calculation or after loading a precomputed dataset), by clicking “File” → “Export” → “3D-point cloud as VRML file”, the following option window will be shown.





You can set the upper left and bottom right corners to define a region by yourself, in which the data will be exported. The ROI size will be changed depending on the coordinates. The default region is the predefined ROI (which is defined by dragging & clicking right mouse). Otherwise, the default region is the whole image size (width * height)

The sample distance defines the density of the sample points in the point cloud. By default it is set to 10, which means, every 10th point will be sampled in horizontal and vertical direction. If the sample distance is set to 1, then every point will be used which can cause a high memory and disk usage.

By clicking the button “Export” you can choose a file name where the result is saved to. If the checkbox “Compress VRML in a zip file” is activated, then a compressed zip file will be generated, which contains the VRML file (*.wrl) and the texture file (*.png).

6.12 View ROI Info / Pixel Info

At the bottom left corner of the 3D-viewer the information about the image ROI, pseudo-color ROI, and the mean distance from the pseudo-color ROI to camera is shown. If no ROI is selected, the size of the full image instead of the size of ROI will be shown.



Gray value at (X: 1843, Y: 2493): 19823. Distance of current point to camera: 150,502 mm. Height difference of current point to pseudo color ROI: -0,040 mm.

When moving the mouse over the image, the info of the pixel value will be shown in the status bar.


Mouse moving over	Height Map Image	Rectified Image	Confidence Map	Raw Image A/B	3D-Model
--------------------------	-------------------------	------------------------	-----------------------	----------------------	-----------------

current image coordinates	yes	yes	yes	yes	no
distance of current point to camera	yes	yes	yes	no	no
Distance difference compared with mean pseudo color ROI	yes if ROI exists	yes if ROI exists	yes if ROI exists	no	no
Further information of current point	Grayscale value of height	Grayscale value of height, RGB	confidence value	RGB	RGB

6.13 Other Functions

6.13.1 Other Menu Bar Functions

The 3D model shows a closed-surface view. You may switch to the point-cloud representation without visualizing the texture by choosing “View” at the menu bar and enabling “Show point cloud”.



Under “View”, you have also the possibility to display the “no value”-points in red.

By clicking “Info” at the menu bar, you can open the manual of 3D-Viewer, or the manual of 3D-API, or your version of the 3D-Viewer is displayed.



6.13.2 Sample Images and Sample Precomputed Data

To get familiar with the 3D-Viewer, test images are provided. You may find them in the application directory.

In Windows 7, with default installation presets, the sample images can be found in the following directory:

C:\Users\Public\Documents\Chromasens\3D\sample images\single camera system

C:\Users\Public\Documents\Chromasens\3D\sample images\two camera system

The raw image name for the single camera system is AB_XXX.bmp, and for the dual camera system the two raw image names are A_XXX.bmp and B_XXX.bmp.

You can find precomputed data of sample images in the following directory, which can be directly loaded in 3D-Viewer: (chapter [6.10.2](#))

C:\Users\Public\Documents\Chromasens\3D\sample images\single camera system\precomputed

C:\Users\Public\Documents\Chromasens\3D\sample images\two camera system\precomputed

NOTE In v2.4a or newer version, the folder of sample images and sample code are moved to C:\Users\Public\Documents\Chromasens\3D


In v2.3e or older version, the folders were under C:\Program Files\Chromasens\3D

6.13.3 Verify Calibration

Each camera was exactly calibrated after being manufactured. If the environment or conditions are changed over time, the original calibration may not provide the same accuracy as before. In this case, the calibration should be checked and eventually readjusted.


The verification process is based on detecting and matching the areas of raw images. So the chosen raw images should fulfil the following criterions. Otherwise the verification may not work successfully.

- a) The object must have a flat surface. Obvious height differences (e.g. from steps or slope) of the surface must be avoided.
- b) The images of the object must be sharp.
- c) Along the whole horizontal direction, the images have to be rich in recognizable textures, patterns or features.




Example of a suitable raw image of a metal surface used for calibration verification

The 3D Viewer provides the possibility to check the validity of the calibration (for calibration version v2.0 or later). The dialog of verifying calibration can be opened by clicking the menu bar “Calculation” → “Verify calibration”, or by using the hotkey “ctrl+v”.




Step 1: choose a configuration file, whose corresponding calibration file should be verified.

By opening the “Verify Calibration” window, the current loaded configuration file will be used for verification by default. If a different configuration file should be used, the user can click the button “Load Other Config File” The file path of the chosen configuration and calibration file will be shown above in text field, and the corresponding camera information will be displayed in the middle area.



Step 2: choose raw image(s) which will be used for calibration verification.



By default, the current loaded raw images will be directly ready for the following verification. The user can pick other raw images for calibration by clicking the button “Load Raw Image(s)”. Ideal raw images for calibration verification should have plenty of recognizable features or textures, which are spread regularly in the horizontal direction.

Step 3: start verification

After loading raw image(s), the verification can be started by clicking the button “Start Verification”. The verification will last several minutes. One of the following results will be shown after the verification

a) Calibration verification is done successfully.

The current calibration is valid. There is no need to adjust the calibration

b) Calibration verification is not successful.

Most probably because the chosen image(s) are not suitable for verification due to too few features or texture in the raw image. The user can then choose new raw images or cancel the verification

c) Calibration is not valid any more.

This indicates that the calculation based on the calibration is not reliable. So the calibration should be adjusted. The user can choose to adjust and **overwrite** the current invalid calibration file or to cancel and quit the verification process. The adjustment of calibration will also last several minutes, In the end, a result of adjustment will be informed as well.


6.13.4 Adjust Pseudo-color Map

The user can mark an ROI by clicking and dragging the left mouse. The height information within this ROI will be displayed as pseudo-color map, where the blue color normally indicates the lower area and red the higher area of this ROI. So in most cases, the color interpretation of a pseudo-color map depends on the chosen ROI, namely depends on the relative height in the ROI. The advantage of this displaying method is that user can get an immediate clear impression of the height distribution of this ROI.

Additionally, 3D-Viewer also provides another possibility to display pseudo-color map in a “global” way, which does not depend on the chosen ROI. Instead, the absolute height range will be used. This means, the points of the same height will always be assigned with the same pseudo-color regardless of how an ROI is chosen. We can open the pseudo-color map display wizard if we want to use this display method.

There are four ways to open the pseudo-color map control wizard


1) Use menu “View” → “Adjust pseudo-color map”



2) Double click on the pseudo-color scale

3) Right click on the pseudo-color scale to open a context menu and then click “Adjust pseudo-color map”

4) Or open the menu “Calculation” → “Options”



Pseudo Color Display Range

Use manual height value as color

display range start (blue) display range end (red)

distance to zero plane -2,456 mm 2,456 mm

By default the display of pseudo-color map does not use absolute height value but use relative value depending on the selected ROI, so option “Use absolute value independent on chosen ROI” is disabled. This option can only be enabled if a valid pseudo-color map is currently marked.

After enable this option, the sliders and numeric updown boxes which indicate the displaying absolute height range will be enabled too. By sliding the thumbs of both sliders, or changing the value of distance values, the pseudo-color map will be updated. The color of pseudo-color map will only depend on the display range start and end. Outside this interval, it will be displayed as black. Even after marking different ROIs, the same area will still have the same pseudo-color distribution. So the visualization of pseudo-color map will not be affected by the chosen ROI any more, if this option is enabled.

Pseudo Color Display Range

Use manual height value as color


display range start (blue) display range end (red)

distance to zero plane -1,444 mm 0,214 mm

If the traditional display method (using relative height depending on ROI) should be used, you can disable the option “Use absolute value independent on chosen ROI” again.

6.13.5 Comparison of Two Areas

In 3D-Viewer, the user is able to mark two areas and then the difference of their average x,y and z values will be displayed.




How to mark two areas to compare their difference:

- 1) To mark the first area, please press “ctrl”-key on the keyboard, and left click the mouse, then release the “ctrl”-key. The first area is marked in yellow green color and it is fixed.
- 2) Move mouse to the second area, left click the mouse to mark it. Then the second area will be marked in royal blue color. There is a line connecting the both areas. And the difference of their average x, y, z values is displayed on the bottom right corner.
- 3) You can just repeat step 2) to choose different second area. The new chosen area will always be used to compare with the first area, which is marked in step 1)
- 4) To remark the first area, please repeat step 1)
- 5) If you want to cancel the mark process, please press the “a”-key on the keyboard.

Currently, the user can adjust the shape (square or circle) and the size of the area. This can be set by


- 1) Opening the menu “Calculation” → “Options” → tab “Visualization Parameters”.
- 2) Or opening the menu “View” → “Area comparison wizard”

The x,y,z values of the pixels within the marked areas will be averaged for the comparison.



6.13.6 Generate System Information Report


Users are able to collect the system information, which can be related to the usage of Viewer. This can be realized by clicking the menu bar “Info” → “Generate system information report”. The following information will be generated and then saved into a log report file.



- Operating system
- Total RAM and current available RAM
- GPU Information
- Chromasens 3D-Viewer Information (Path, existing dll files and their version, etc)
- LabVIEW installation information
- Camera Setup Tool (CST) installation information
- Current camera connection (which camera is connected, camera type and id, etc)
- Camera Link file installation information
- HALCON installation information (root path, version, etc)
- All windows driver file information (file path, name, date, description version, etc)

6.13.7 License Information

The license of 3D-Viewer is written in dongle. Its information can be retrieved by clicking the menu bar “Info” → “License information”




The information contains:

- License type (single or multiple license)
- License count (the maximal allowed number of instances simultaneously)
- Expiration date
- Serial number of the license

6.13.8 Check for Updates

By clicking the menu bar “Info” → “Check for updates”, the program will try to connect the server of Chromasens and then search for the newest software version. One of the three messages will be shown after clicking.

- 1) There is no internet connection
- 2) The current version of 3D software package is up to date.
- 3) There is a newer version of 3D software package. If this appears, you can decide to download / update the newer version or just use the current 3D-Viewer without updating.



7 Advanced

7.1 Command-Line Parameters

7.1.1 General Parameters

<code>--configFile [fn]</code>	Loads the configuration file [fn] at the start of the viewer
<code>--listen [port]</code>	Listens on local-port [port] for remote control commands. See the separate “3DViewer Remote Control Protocol” documentation for a description of the protocol.
<code>--mode load [fn] [[fn2]]</code>	Loads automatically the source-image with the given filename [fn] or load an source image pair with the filenames [fn] and [fn2], after the viewer is started
<code>--mode loadAndCalc [fn] [[fn2]]</code>	Same as “--mode load” but also starts the calculation.
<code>--movingDemo [msec]</code>	Starts to rotate the 3D-model after [msec] milliseconds of mouse-inactivity. The rotation is disabled, if the mouse is placed over the 3D-model window.
<code>--offline</code>	Presents offline data. In offline mode, no calculation is possible, and no dongle is needed. It is used to avoid the “No license” error message

7.1.2 Calculation Parameters

The following parameters enable the possibility to set an initial value direct on startup of the viewer.

<code>--minGrayVal [intVal]</code>	Minimum gray value used for calculation [0 ... 255]
<code>--maxGrayVal [intVal]</code>	Maximum gray value used for calculation [0 ... 255]
<code>--minStdDevA [floatVal]</code>	Minimum contrast [0.00 ... 255.00]
<code>--minKkf [floatVal]</code>	Minimum cross-correlation factor [0.00 ... 1.00]
<code>--maxConsistent [intVal]</code>	Max difference between with correlation from left to right and right to left in pixels. [0 ... 100]
<code>--dStart [intVal]</code>	Lower height range limit that is considered.
<code>--dEnd [intVal]</code>	Upper height range limit that is considered.
<code>--windowType [intVal]</code>	correlation window type for the calculation

7.2 Configuration File Properties

The configuration file accesses information stored in the calibration file “calibration.ini”. It is therefore important that the directory of the calibration file is correct.

The following illustration shows how the calibration file is accessed by the configuration file:




Figure 1 - Configuration File

Errors may occur when loading a configuration file that directs to a non-existing calibration file.

- By saving the 3D data with the “Save calculated image-data” function (chapter 6.10), a configuration file is created, which directs to the calibration file created in the same folder.
- By saving the configuration file with the “Save” and “Save as” function of the “Configuration window”, the configuration file will save the directory of the calibration file used in the previous configuration file and always access the calibration file of the saved directory.
- By saving the configuration file with the “Save current config as default” function of the configuration window”, a configuration file and a calibration file are created in the directory: C:\Users\Public\Documents\Chromasens\3D\viewer settings.

Chromasens GmbH
Max-Stromeyer-Straße 116
78467 Konstanz
Germany

Phone: +49 7531 876-0
Fax: +49 7531 876-303

www.chromasens.de
info@chromasens.de