



Hardware - Software Interface

(HSI)

allPixa camera

Revision: 1.12

Change History:

Date	Version	Description	Author
06.06.2012	R1.0	Initial Version based on former document	Musterle
15.02.2014	R1.1	allPIXA updated to camera firmware revision P1.4x	U. Bellmann
05.06.2014	R1.11	Reading of external trigger signals extended (TAG_STATE_EXT_INPUT 0x245) Correction of some parameter ranges	U. Bellmann
25.07.2014	R1.12	Meaning of external trigger signals corrected (TAG_STATE_EXT_INPUT 0x245)	U. Bellmann

Table of contents

1. INTRODUCTION	6
1.1 Purpose	6
1.2 Scope	6
1.3 Terms and abbreviations	6
1.4 General HSI structures	6
1.4.1 General statement on commands	6
1.4.2 General statement on responses	7
2. TAG STRUCTURE	8
2.1 General	8
2.2 BIN format	8
2.3 Short format	8
2.4 Long format	8
2.5 VAR format	9
2.6 CONT format	9
3. BL: CLEAR ERROR STATES	10
3.1 Format of Command BL	10
3.2 Format of the Response bl	10
4. DE: DOWNLOAD END	10
4.1 Format of the Command DE	10
4.2 Format of the Response de	10
5. DR: DOWNLOAD RESET	10
5.1 Format of the Command DR	10
5.2 Format of response	10
6. FE: GENERAL ERROR MESSAGE	11
6.1 Format of the Response fe	11
7. MK: MANAGE CAMERA PARAMETER	13
7.1 Format of the Command MK	13
7.2 Current gain values of the camera	15
7.3 Desired level of the white reference	15
7.4 Gain warn level	15
7.5 Minimum Gain Level	16
7.6 Switch White Control On/Off	16
7.7 Set test pattern	16
7.8 Set first pixel of the white reference area absolute	17
7.9 Set number of pixel for white reference area	17
7.10 Show the borders of white reference area in video data	17
7.11 Set Average Mode	17
7.12 Set Gamma	18
7.13 Select Shading correction on/off	18
7.14 Select Black level correction on/off	18
7.15 Usage of color conversion on/off	18
7.16 First valid scan line within an image	18
7.17 Set number of scan lines within an image	19
7.18 Set first valid Pixel within a scan line	19
7.19 Set length of a scan line	19
7.20 Scan pattern	19
7.21 Linetrigger reduction factor	20
7.22 Set scan direction	20

7.23	Mode of horizontal synchronization	21
7.24	Start Scan Mode	21
7.25	Store setting in non-volatile memory	21
7.26	Activate stored setting in camera	21
7.27	Physical resolution in transport direction	22
7.28	Mirror scan line	22
7.29	Comment for Setting	22
7.30	Set Integration time in ns	22
7.31	Set Scan Condition	22
7.32	Set special register values in camera (use only for development)	23
7.33	Indicate Setting for Store	23
7.34	Set description text for the camera	23
7.35	Set private data	24
7.36	Set initial gain level	24
7.37	Update initial gain level	24
7.38	Set maximum number of scan lines	24
7.39	Stop at max number of scan lines	25
7.40	Set additional paper length	25
7.41	Encoder parameter	25
7.42	Setting Verify ID	26
7.43	Select reference data set for black level correction	27
7.44	Select reference data set for white level correction	27
7.45	Set number of white reference samples for average	27
7.46	Select mode for white reference	27
7.47	Select insert information to video data	28
7.48	Color channel for MuxOutCol	29
7.49	Change Red / Blue color channel	29
7.50	Enable camera link high speed	29
7.51	Horizontal binning	30
7.52	Set register parameter to setting	30
7.53	Set first pixel of white reference area relative to image window	30
7.54	Set first scan line of white reference area in transport direction	31
7.55	Set number of lines for white reference area	31
7.56	Set value for stop gain control	31
7.57	Set White Reference visible mode	32
7.58	Clear Setting content	32
7.59	Use absolute position of white reference in CCD direction	32
7.60	Select position for insert information	32
7.61	Enable Line period at free run (Shutter Mode at Free run)	32
7.62	Set Line period at free run (Shutter Mode at free run)	33
7.63	Enable Keystone correction	33
7.64	Parameters for Keystone correction	33
7.65	Select data set for color conversion method	34
7.66	Select the camera link transfer speed	34
7.67	Set weights for the color channels	34
7.68	Set reduction mode in transport direction	35
7.69	Set trace mask	35
7.70	Modify Video level with brightness and contrast control	35
7.71	Master-Slave-Control	36
7.72	Set white Control mode	36
7.73	RGB line distance between the color lines of a tri-linear sensor	37
7.74	Set grey video out mode	37
7.75	Set value for test pattern	38
7.76	Set Gain in the pre amplifier stage	38
7.77	Select Type of Camera Link Interface	38
7.78	Set External Signal Assignment	38
7.79	Use an assignment table from another setting	40
7.80	Format of the Response mk	40

8. MS: MAINTENANCE SENSORS

42

8.1	Format of the Response ms	42
-----	---------------------------	----

42

8.2	Environment Values	42
8.3	Common values	43
9.	MR: TAKE REFERENCE	45
10.	WR: CHECK WHITE CONTROL STATUS	46
11.	TA: TAP ADJUSTMENT	47
11.1	Format of the Command TA	47
11.2	Format of the Response ta	47
12.	PA: PARAMETERS FOR ALL UNITS	48
12.1	Format of the Command PA	48
12.2	Format of the Response pa	48
12.3	PA Tags and Parameter (TAG-IDs)	48
13.	PK: CONFIGURATION TEST	50
13.1	Format of the Command PK	50
13.2	Format of the Response pk	50
13.3	List of Tags which are specific to request	56
14.	RS: REQUEST STATE	57
14.1	Format of the Command RS	57
14.2	Format of the Response rs	57
15.	DD: DOWNLOAD DIGITAL FILTERS	58
15.1	Format of the Command DD	58
15.2	Format of the Response dd	60
16.	DS: DOWNLOAD REFERENCE DATA	61
17.	DV: DOWNLOAD EXTERNAL IO CONFIGURATION DATA	63
18.	UV: UPLOAD EXTERNAL IO CONFIGURATION DATA	64
19.	APPENDIX	64

1. Introduction

1.1 Purpose

This document defines the HSI data dictionary for Chromasens cameras of allPixa family.

It refers to camera package release P1.40

1.2 Scope

This document describes the structure of the HSI commands (also called HSI Order) It describes the several commands and the response returning from the camera.

1.3 Terms and abbreviations

Abbreviation	
HSI	Hardware Software Interface
TAG	Parameter structure for HSI commands

1.4 General HSI structures

1.4.1 General statement on commands

The structure of a command with no specific information, i.e. a command that consists only of the header and the checksum, is shown below. For reasons of economy the structure of such a minimum Command is not repeated throughout this document but is explained only once in the following:

15	8	7	0	
X		Y		0 Name
Low word length				2 Length
High word length				4 Length
reserved		reserved		6
reserved		reserved		8
Checksum				10 Check sum

Name: = 'X' 'Y'

The name field contains an abbreviation of the Command name consisting of two **upper-case ASCII characters**. The first character resides in the high byte.

Length:

The Length field consists of 2 words and is a 32 bit unsigned integer that states the length (word count) of the data following on the Receiver word and including the Checksum word.

For the minimum Command the length value is 1 if no data words are included to the Command (Low word length = 0001 H).

Check sum

This field contains the modulo 2^{16} sum of all words of the Command, except for the check sum word.

Remarks

All reserved bytes of a command or response must be set to zero.

Commands that contain additional information the data is follow by reserved words before the checksum. The length field is adapted appropriate.

1.4.2 General statement on responses

Since, generally, each Command must be answered by a response even if there are no specific response data, there is a minimum response consisting only of the header and the checksum. This response serves only as an acknowledgement of a preceding Command. For reasons of economy the structure of a minimum response is not repeated throughout this document but is explained only once in the following:


15	8	7	0	
x		y		0 Name
Low word length				2 Length
High word length				4 Length
Sender				6 Sender
reserved		reserved		8
Checksum				10 Check sum

- Name:** = 'x' 'y' The Name field of a response echoes the 2 character name of the corresponding Command, but is written **in lower-case characters**. (Command names consist of 2 upper-case characters.) The first character resides in the high byte.
- Length** The Length field consists of 2 words and is a 32 bit unsigned integer that states the length (word count) of the response data following on the Receiver word and including the Checksum word.
For the minimum response the Length value is 1 (Low word length = 0001 H).
- Sender** This field contains the name of the camera-board, which has transmitted the response message
 = xxxx H: Board identifier (2 ASCII characters)
 = 'K1' Camera board KAx No.1
 = 'K2' Camera board KAx No.2
 = 'K3' Camera board KAx No.3
 = 'K4' Camera board KAx No.4
- This is used in systems with more than one Camera board. By default (in single camera systems) the camera has the ID "K1"
- Checksum** This field contains the modulo 2¹⁶ sum of all words of the response, except for the check sum word.

2. Tag structure

2.1 General

A tag is a data block which contains certain information defined by the tag header. Tags are structured into 16-bit words and have the following general structure:




Meaning of the terms:

- Format: Identifies the data format. There are 5 different formats (see below).
- TAG-ID: The tag identifier states which type of data is contained in the data words.
- Length: If a length field exists, it contains the number of the subsequent data words.
- Data word n: Data of the tag with the actual information.

The following tag formats exist:


2.2 BIN format



- Format = 000 (bin) : The Boolean value of the tag is '0'
- Format = 001 (bin) : The Boolean value of the tag is '1'

This binary tag consumes one (16-bit) word. Its Boolean value, either 0 or 1, is determined by the last bit of the format field (bit 2¹³).


2.3 Short format



Format = 010 (bin)

The information is contained in the 16-bit word following on the tag header. Obviously, all tags with no more than 16 bit of information can be implemented as Short format tags.


2.4 Long format



Format = 011 (bin)

The information is contained in the 32-bit dword following on the tag header.


2.5 VAR format



Format = 100 (bin)

The VAR format is defined for tags of variable data length. The length values 0 or 1 are also permissible.


2.6 CONT format



Format = 101 (bin)

This tag is named a container tag. The data part summarizes several, logically associated tags. The individual tags in the data part of the container tag can themselves in turn be container tags. Thus, nested containers can be built.

Example:



3. **BL: Clear Error States**

BL clears errors with following internal actions:

- Clear internal error memory
- Clear error state at external display (if exists)
- Clears error outputs (if exists)

3.1 **Format of Command BL**

The **BL** Command has no specific data (see 1.4.1 General statement on commands)

3.2 **Format of the Response bl**

The **bl** response has no specific data (see 1.4.2. General statement on responses).

4. **DE: Download End**

This command is used together with the PA Command. It signalizes the download of PA Commands are completed.

4.1 **Format of the Command DE**

The **DE** Command has no specific data (see 1.4.1 General statement on commands)

4.2 **Format of the Response de**

The **de** response has no specific data (see 1.4.2. General statement on responses).

5. **DR: Download Reset**

The DR Command is used to reset the camera software.

5.1 **Format of the Command DR**

The **DR** Command has no specific data (see 1.4.1 General statement on commands)

5.2 **Format of response**

Because of the internal reset no Response is sent!

6. fe: General Error Message

The **fe** response is delivered as an error response after errors an internal fault was detected. The error code and the state information are contained in the response.

The fe response can be sent as response to any Command instead of expected response.

6.1 Format of the Response fe

15	8	7	0	
f		e		0 Name
Length low word				2 Length
High word length				4 Length
Sender				6 Sender
0		0		8
0		0I		10 see below
ECO		ECL		12 Error entry
0		ECE		14 see below
0		ERLEN		16 see below
ERINF1		ERINFO		18 see below
...		...		
...		...		
Check sum				Check sum

ECL = xx H: Error class

ECO = xx H: Error code

ECE = xx H: Error code extension

ERLEN = xx H: Length of the error information (byte count)
The maximum length of the error information is 128 bytes.

ERINF_n = xx H: Error information (freely available for error information)
If the length field ERLEN contains an uneven value, so that the error information does not end at a word boundary, then the last word must be filled up with a 0 byte.

Note on the error classes

Error class 1: Class 1 errors (warning) can be reported as a fe response to all Commands.

Error class 2: Class 2 errors (indication of internal error) can be reported as fe response to all Commands.

Error class 3: Class 3 errors (parameter errors) can be reported as fe response only to parameter commands.

Error class 4: Class 4 errors (initializing error) can be reported as fe response to all Commands. The reasons for these errors are internal checks.

Error class 5: Class 5 errors (reportable HW or SW errors) can be reported as fe response to all Commands. Afterwards the device enters the error state.

ECE represents the last detected error.

If ERLLEN is greater 0 then further errors are reported in the fe response in the following format:

15	8	7	0
ERROR			
Error class			
TAG causing the error (if available)			
Order causing the error (if available)			

Up to 10 further errors can be reported.

7. MK: Manage camera parameter

The Command is used to change parameter of camera.

If parameters are changed which are relevant to image processing inconsistent or corrupted image may occur.

7.1 Format of the Command MK

15	8	7	0	
M		K		0 Name
Low word length				2 Length
High word length				4 Length
reserved		reserved		6 Sender
reserved		reserved		8 Receiver
reserved				10 Data, see below
Parameters for camera in TAG format				12
Check sum				Check sum

The parameters are structured as tags.

Gain Control Tags

TAG_SET_GAIN	(1C0 H)
TAG_SET_POINT_WHITE_REFERENCE	(1C2 H)
TAG_SET_GAIN_WARN_LEVEL	(1C4 H)
TAG_SET_MINIMUM_GAIN_LEVEL	(1C5 H)
TAG_USE_WHITECONTROL	(200 H)
TAG_SET_HORIZONTAL_POSWREF_ABSOLUTE	(223 H)
TAG_SET_HORIZONTAL_WREF_LENGTH	(224 H)
TAG_SHOW_WHITEREF_BORDERS	(226 H)
TAG_USE_FASTINCREMENTAL_AT_WARMINGUP	(22F H)
TAG_SET_INITIAL_GAIN_LEVEL	(267 H)
TAG_UPDATA_INITIAL_GAIN	(268 H)
TAG_SET_WHITEREF_AVERAGE	(283 H)
TAG_SEL_WHITEREFPOS	(287 H)
TAG_SET_HORIZONTAL_WREF_START	(2A1 H)
TAG_SET_VERTICAL_WREF_START	(2A3 H)
TAG_SET_VERTICAL_WREF_LENGTH	(2A4 H)
TAG_SET_GAIN_STOPP_FACTOR	(2A5 H)
TAG_SET_WREF_VISIBLE_MODE	(2A6 H)
TAG_USE_HORIZONTAL_WREF_START_ABSOLUTE	(2A9 H)
TAG_SET_WHITECONTROL_MODE	(318 H)
TAG_SET_CDS_GAIN	(3A0 H)

Reference Data Tags (Black and White)

TAG_USE_SHADING_CORRECTION	(22A H)
TAG_USE_BLACKLEVEL_CORRECTION	(22B H)
TAG_SEL_REFERENCEDATA_BLACK	(280 H)
TAG_SEL_REFERENCEDATA_WHITE	(281 H)

Image Processing Tags:

TAG_SET_TESTPATTERN_MODE	(222 H)
TAG_SET_AVERAGEMODE	(228 H)
TAG_SET_GAMMA_VALUE	(229 H)
TAG_USE_COLOR_CONVERSION	(22C H)
TAG_MIRROR_DATA_HOR	(246 H)
TAG_SET_BINNING	(29AH)

TAG_USE_KEYSTONECORRECTION	(2b8 H)
TAG_SET_KEYSTONECORRECTION	(2b9 H)
TAG_SEL_CCM	(2BB H)
TAG_SET_COLOR_WEIGHTS	(305 H)
TAG_VIDEOLEVEL_CORRECTION	(315 H)
TAG_USE_IP_FILTER_HOR	(316 H)
TAG_SET_TESTPATTERN_LEVEL	(323 H)

Video Output Interface:

TAG_SET_VIDEOOUT_MODE	(265 H)
TAG_SET_INSERT_MODE	(293H)
TAG_MUX_OUT_COLOR_SELECT	(295H)
TAG_R_B_CHANGE	(296 H)
TAG_COLUMN_INSERTMODE	(2B0 H)
TAG_SELECT_CL_SPEED	(2BCH)
TAG_SET_GREYOUTPUT_MODE	(322 H)
TAG_SET_CAMERALINK_INTERFACE	(3A1H)

Trilinear/OddEven sensor support tags:

TAG_SET_RGB_LINEDISTANCE	(319 H)
TAG_SET_SCANDIR	(23A H)

Sync signal Generation Control Tags:

TAG_SET_VSYSTART	(230 H)
TAG_SET_VSYLENGTH	(231 H)
TAG_SET_HSYSTART	(232 H) (obsolete with camera release P1.40)
TAG_SET_HSYLENGTH	(233H)
TAG_SET_INTEGRATION_TIME_IN_NS	(24A H)

TAG_SET_SCANCONDITION	(24B H)
TAG_SET_SCANPATTERN	(237 H)

TAG_SET_SCAN_READY	(23C H)
TAG_SET_MAX_NUMBER_SCANLINES	(271 H)
TAG_STOP_BY_MAX_NUMBER_SCANLINES	(272 H)
TAG_SET_VSY_OVERSIZE	(273 H)
TAG_USE_LINEPERIOD	(2b6 H)
TAG_SET_LINEPERIOD	(2b7 H)
TAG_MASTER_SLAVE_CONFIGURATION	(317 H)
TAG_SET_SUPPRESSED_LINES	(30E H)

Encoder control:

TAG_SET_TRANSITIONS_PER_LINE	(238 H)
TAG_USE_EXTERNALSYNC	(23B H)
TAG_SYNCMODE_EXTENDED	(279 H)

Manage Settings:

TAG_BURN_SETTINGS	(240 H)
TAG_SET_ACTIVE_SETTING	(241 H)
TAG_SET_SETTING_STOREFLAG	(258 H)
TAG_SETTING_VERIFY	(27c H)
TAG_SETTING_CLEAR	(2A7 H)

Other TAGs:

TAG_PHYS_AUFL_HOR	(243H)
TAG_PHYS_AUFL_VERT	(244H)
TAG_COMMENT	(247H)

TAG_SET_CAMERA_DESCRIPTION_TEXT	(264 H)
TAG_SET_PRIVATE_DATA	(266 H)
TAG_REGISTER_TO_SETTING	(29D H)
TAG_SET_TRUE_RES	(303 H)
TAG_SET_TRACE_MASK	(30F H)

Manage the external IOs

TAG_SET_EXTERNAL_SIGNAL_ASSIGNMENT	(701 H)
TAG_SET_EXTERNAL_SIGNAL_ASSIGNMENT_REFERENCE	(702 H)

7.2 Current gain values of the camera

Set the current gain values for the video channels. Every channel is separate programmed. Change of these values is only possible if the white control is switched off.

TAG-ID:	TAG_SET_GAIN = 1C0 H	
Format:	VAR	
Data:	1 st word:	Red odd gain value
	2 nd word:	Red even gain value
	3 rd word:	Green odd gain value
	4 th word:	Green even gain value
	5 th word:	Blue odd gain value
	6 th word:	Blue even gain value
	7 th word:	Rear red odd gain value
	8 th word:	Rear red even gain value
	9 th word:	Rear green odd gain value
	10 th word:	Rear green even gain value
	11 th word:	Rear blue odd gain value
	12 th word:	Rear blue even gain value

Values:	0 ... 700
Default:	640

7.3 Desired level of the white reference

Set the target values for the area of white reference. Each channel value (RGB, Odd/ Even, front/rear tab) is set separate.

TAG-ID:	TAG_SET_POINT_WHITE_REFERENCE = 1C2 H	
Format:	VAR	
Data:	1 st word:	Red odd camera value
	2 nd word:	Red even camera value
	3 rd word:	Green odd camera value
	4 th word:	Green even camera value
	5 th word:	Blue odd camera value
	6 th word:	Blue even camera value
	7 th word:	Rear red odd camera value
	8 th word:	Rear red even camera value
	9 th word:	Rear green odd camera value
	10 th word:	Rear green even camera value
	11 th word:	Rear blue odd camera value
	12 th word:	Rear blue even camera value

Values:	0 ... 1023
Default:	640

7.4 Gain warn level

If calculated gain level exceeds the gain warn level then a “fe response” is generated after request by Command WR. Each channel value (RGB, Odd/ Even, front/rear tab) is set separate.

TAG-ID:	TAG_SET_GAIN_WARN_LEVEL = 1C4 H
---------	---------------------------------

Format: VAR
 Data: 1st word: Red odd camera value
 2nd word: Red even camera value
 3rd word: Green odd camera value
 4th word: Green even camera value
 5th word: Blue odd camera value
 6th word: Blue even camera value
 7th word: Rear red odd camera value
 8th word: Rear red even camera value
 9th word: Rear green odd camera value
 10th word: Rear green even camera value
 11th word: Rear blue odd camera value
 12th word: Rear blue even camera value

Values: 0 ... 700
 Default: 640

7.5 Minimum Gain Level

Values are limits that can be used in processing of WR- order to ensure minimum gain values within adjustment process. Each channel value (RGB, Odd/ Even, front/rear tab) is set separate.

TAG-ID: TAG_SET_MINIMUM_GAIN_LEVEL = 1C5H
 Format: VAR
 Data: 1st word: Red odd camera value
 2nd word: Red even camera value
 3rd word: Green odd camera value
 4th word: Green even camera value
 5th word: Blue odd camera value
 6th word: Blue even camera value
 7th word: Rear red odd camera value
 8th word: Rear red even camera value
 9th word: Rear green odd camera value
 10th word: Rear green even camera value
 11th word: Rear blue odd camera value
 12th word: Rear blue even camera value

Values: 0 ... 700
 Default: 0

7.6 Switch White Control On/Off

Tag for enable or disable the white control function

TAG-ID: TAG_USE_WHITECONTROL = 200 H
 Format: Bin
 Data: 0 : White Control off
 1 : White Control on

Default:

7.7 Set test pattern

This tag enables/disables the test pattern mode and selects the type of test pattern. If test pattern is activated synthetic test data is sent as image data instead of video data from camera sensor.

TAG-ID: TAG_SET_TESTPATTERN_MODE = 222 H
 Format: Short
 Data: 0 : No pattern
 1 : Grey ramp in CCD-Direction
 2 : Grey ramp in transport direction
 3: ramp 0..1023 internal on green Channel
 value set by TAG_SET_TESTPATTERN_VALUE (323H) on red and blue channel

- 4: Sequence of different test patterns and live image
- 5: change video level at every pixel

Default: 0: No pattern

7.8 Set first pixel of the white reference area absolute

This tag describes the position for the white reference in scan line direction.

Pixel position defined with TAG_SET_HORIZONTAL_POSWREF_ABSOLUTE is meant absolute beginning with first pixel of the camera sensor.

Pixel position can also be defined relative to actual active image window with TAG_SET_HORIZONTAL_WREF_START (2A1 H).

If TAG_USE_HORIZONTAL_WREF_START_ABSOLUTE (2A9H) is set then absolute position is used.

TAG-ID: TAG_SET_HORIZONTAL_POSWREF_ABSOLUTE = 223 H

Format: Short

Data: 0 to line length of the sensor

Default: 0

7.9 Set number of pixel for white reference area

This tag defines the number of pixel / columns for the white reference area in scan line direction.

TAG-ID: TAG_SET_HORIZONTAL_WREF_LENGTH = 224H

Format: SHORT

Data: Number of pixels or columns used for white reference area .Only even values were supported.
0 ... 1022

Default values: 20

7.10 Show the borders of white reference area in video data

This tag enables/ disables the function to show the borders of the white reference in the image.

Hints: To see borders in the video data the start and end positions must be within the active scan window. The visible mode must be disabled by collecting images for offset and shading correction.

TAG_ID: TAG_SHOW_WHITE_REF_BORDERS = 226H

Format: SHORT

Data: 1: Position of white reference borders in video data visible
0: Position of white reference borders in video date not visible

Default: 0

7.11 Set Average Mode

To get a better picture quality it is useful to average successive lines. But this slows the speed of the camera. If average mode is set to n lines the speed has to be reduced to 1/n to keep the image ratio.

TAG-ID: TAG_SET_AVERAGEMODE = 228 H

Format: SHORT

Data: 0: No Average
n: Average scan line with (n + 1) Lines

Range: 0 ... 15

Default: 0: No Average

7.12 Set Gamma

Gamma modifies the input values in all color channels: $out_value = round(255 (normalized\ in_value)^{1/Gamma})$

TAG-ID: TAG_SET_GAMMAVALUE = 229 H

Format: Short

Data: 0: gamma correction not used
1 ... 25: set gamma in range value divided by 10 (0.1 ... 2.5)

Default: 0: gamma correction not used

7.13 Select Shading correction on/off

This tag enables / disables the shading correction. If enabled the stored shading reference data are loaded for correction.

With TAG_SEL_REFERENCEDATA_WHITE (281 H) the white reference data set is selected.

TAG-ID: TAG_USE_SHADINGCORRECTION = 22A H

Format: Bin

Data: 0: Shading correction disabled
1: Shading correction enabled

Default: 0: Shading correction disabled

7.14 Select Black level correction on/off

This tag enables the black level correction (Offset correction). If enabled the stored black level reference data are loaded to correct the black level.

With TAG_SEL_REFERENCEDATA_BLACK (280 H) the black reference data set is selected.

TAG-ID: TAG_USE_BLACKLEVELCORRECTION = 22B H

Format: Bin

Data: 0: Black level correction disabled
1: Black level correction enabled

Default: 0: Black level correction disabled

7.15 Usage of color conversion on/off

This tag enables/ disables the color conversion function. Method and color conversion data are supported by order DD.

TAG-ID: TAG_USE_COLOR_CONVERSION = 22C H

Format: Bin

Data: 0: Color Conversion disabled
1: Color Conversion enabled

Default: 0: Color Conversion disabled

7.16 First valid scan line within an image

This tag defines the value of the first valid scan line within an image after a trigger event.

If a camera is in slave mode the value defines an offset to the first valid scan line position of the master camera.

TAG-ID: TAG_SET_VSYSTART = 230 H
Format: SHORT
Data: First valid scan line in range 0 to 32767
Default: 300

7.17 Set number of scan lines within an image

This tag defines the number of scan lines within an image. If scan condition mode 2 (TAG_SET_SCANCONDITON) is selected this function is not active.

TAG-ID: TAG_SET_VSYLENGTH = 231 H
Format: SHORT
Data: 1. word: number of scan lines
Range: 1 .. 65535
Default: 2704

7.18 Set first valid Pixel within a scan line

This tag defines the first valid pixel in image in scan line direction.

TAG-ID: TAG_SET_HSYSTART = 232 H (obsolete with camera release P1.40 and higher)
Format: SHORT
Data: 1. word: first valid pixel
Range: 0 ... length of sensor / 2
Default: 0

7.19 Set length of a scan line

This tag defines the value of the image width in scan line direction.

TAG-ID: TAG_SET_HSYLENGTH = 233H
Format: SHORT
Data: 1. word: number of pixel within a scan line
Range: 2 ... length of sensor
Default: 5000

7.20 Scan pattern

With this tag the triggering synchronization with external signals like light barriers is configured.

TAG-ID: TAG_SET_SCANPATTERN = 237 H
Format: VAR

Data: Data for Start Scan Control

Bit	15	0	
	ScanPattern Mask		Word 0
	ScanPattern 0		Word 1
	ScanPattern 1		
	ScanPattern 2		
	ScanPattern 3		Word 4

Mask: With one bit out of bits 0 .. 3 set to "1" a trigger input signal is selected.

With bits 0 .. 3 of the pattern words the polarity of the trigger signal is configured.

Example:

- LB1 is trigger signal
- rising edge
- only start trigger is used.

Bit	15	3	2	1	0			
ScanPattern Mask				0	0	1	0	Word 0
ScanPattern 0				0	0	0	0	Word 1
ScanPattern 1				0	0	0	0	
ScanPattern 2				0	0	1	0	
ScanPattern 3				0	0	1	0	Word 4

Bit 2¹ of mask selects LB1.

Sequence of 0-0-1-1 at bit 2¹ in pattern 0..3 corresponds to a rising edge of the signal.

If TAG_SET_SCANCONDITON (24B H) is set to start and stop condition then pattern 0 and 1 defines the start condition and pattern 2 and 3 the stop condition.

7.21 Linetrigger reduction factor

The selected factor with this tag is used to reduce the transport resolution in linetrigger and encoder mode. The factor is the reciprocal of the inserted value in the range from 1 to 256.

TAG-ID: TAG_SET_TRANSITIONS_PER_LINE (238 H)

Format: SHORT

Data: 1: No reduction is used
2 ... 256: value for line reduction factor (1/value)

Default: 0: No reduction is used

7.22 Set scan direction

This tag selects the sequence of color lines of the tri-linear CCD-Sensor (RGB or BGR). The sequence needs to be changed by changing the scan direction.

TAG_SET_SCANDIR determines the direction of the RGB line shift done in the camera.

If external synchronization mode is selected (TAG_USE_EXTERNAL_SYNC = 1) the camera detects the scan direction by the incremental encoder. In this mode the tag is used to determine the meaning of encoder signal.

TAG-ID: TAG_SET_SCANDIR = 23A H

Format: Bin

Data: 0: red line first / incremental encoder signal not inverted
1: blue line first/ incremental encoder signal inverted

Default: 0: red line first / incremental encoder signal not inverted

7.23 Mode of horizontal synchronization

With this tag encode / line trigger mode of the camera is enabled.

The parameters for the encoder are set with TAG_SYNCMODE_EXTENDED (279 H).

TAG-ID: TAG_USE_EXTERNAL_SYNC = 23B H

Format: Bin

Data: 0: scan line is free running with parameter integration time / line period
1: scan line synchronization with external signal (encoder)

Default: 0

7.24 Start Scan Mode

This tag enables/ disables the scan line generation.

TAG-ID: TAG_SET_SCAN_READY = 23C H

Format: Bin

Data: 0: Generation of image line is disabled
1: Generation of images line is enabled

Default: 1

7.25 Store setting in non-volatile memory

With this tag the current configuration of the camera is stored in the selected slot of Setting to the non-volatile memory.

TAG-ID: TAG_BURN_SETTINGS = 240 H

Format: SHORT

Data: 1..19: Selected setting number to store configuration

With all other values the tag is ignored

7.26 Activate stored setting in camera

This tag activates a stored setting data set out of the non-volatile memory in the camera. Selected setting must be stored with TAG_BURN_SETTING.

TAG-ID: TAG_SET_ACTIVE_SETTING = 241 H

Format: SHORT

Data: 0: default factory values
1 - 19: number of setting to configure camera

With all other values the tag is ignored

7.27 Physical resolution in transport direction

The value is used to calculate the parameters for the encoder.

TAG-ID: TAG_PHYS_AUFL_VERT = 244 H
 Format: LONG
 Data: 0 ... FFFFFFFF H, unit is 1/1000 dpi
 Default: 400000 (1/1000 dpi)

7.28 Mirror scan line

This tag enables/ disables the function to mirror the data output of the scan line horizontally.

TAG-ID: TAG_MIRROR_DATA_HOR = 246H
 Format: Bin
 Data: 0: don't mirror data
 1: mirror data
 Default: 0: don't mirror data

7.29 Comment for Setting

With this tag a comment of maximum 128Byte (ASCII character) can be added to a setting.

Hint: TAG 240H is used to store the complete setting with the comment to the non-volatile memory.

TAG-ID: TAG_COMMENT = 247 H
 Format: VAR
 Data: Text for Comment (ASCII characters)
 Maximum Length = 128 Bytes
 End of text is marked with string end byte = 0
 Default: No comment

7.30 Set Integration time in ns

This tag defines the value of integration time for the CCD sensor in ns.

TAG-ID: TAG_SET_INTEGRATION_TIME_IN_NS = 24A H
 Format: long
 Data: Integration value in ns
 minimum integration time depends on camera speed and sensor length
 max.: 12ms
 Default: 100.000

7.31 Set Scan Condition

This tag selects the type of scan condition. The selected scan condition is configured with additional tags.

The start and stop conditions are set by TAG_SET_SCANPATTERN.

With TAG_SET_VSYSTART the start offset for frame start behind the start condition is set.

With TAG_SET_VSY_OVERSIZE the number of scan lines behind the stop condition end is set.

TAG-ID: TAG_SET_SCANCONDITON = 24b H

Format: SHORT

Data: 0: Do not use Scan Conditions (Free running)
 1: Use Start condition defined
 2: Use Start and Stop condition

Default: 0: Do not use Scan Conditions (Free running)

7.32 Set special register values in camera (use only for development)

With this tag camera internal register can be set directly. The range of functionality for this tag depends on the HW type.

Hint: Values sent with TAG_SET_REGISTER (250H) are not stored in the camera. If storing is needed use Tag 29D H.

TAG-ID: TAG_SET_REGISTER = 250 H

Format: VAR

Data: Register address and register data

Bit	15	0	
	Address 1 relative to FPGA_A		Word 1
	Data word 1 to write in Register		Word 2
	Address 2 relative to FPGA_A		
	Data word 2 to write in Register		
	...		
		Word n

7.33 Indicate Setting for Store

This flag indicates the actual setting to be stored previously in non-volatile memory. When requesting the camera which settings are stored only setting with “stored” flag are set to be active in response tag TAG_GET_USED_SETTINGS (257 H).

TAG_ID: TAG_SET_SETTING_STOREFLAG = 258 H

Format: BIN

Data: 1: indicates that the function “Save all Settings” should include this Setting.
 0: else

Default: 0

7.34 Set description text for the camera

With this tag a camera specific description can be stored in the camera.

Hint: The text is not setting specific.

TAG-ID: TAG_SET_CAMERA_DESCRIPTION_TEXT = 264 H

Format: VAR

Data: Text for Comment (ASCII)
 Maximum length = 256 Bytes
 End of text must marked with a byte with value x00

7.35 Set private data

With this tag 16 words of customer data can be stored in the camera. The content or meaning is arbitrary and not checked by the camera.

TAG-ID: TAG_SET_PRIVATE_DATA = 266 H

Format: VAR

Data: User data
Maximum length = 16 Words

The data is not setting specific and is always stored after receiving.

7.36 Set initial gain level

This tag sets the startup gain values for the camera. These values are also loaded when activating a setting with TAG_SET_ACTIVE_SETTING (241 H).

TAG-ID: TAG_SET_INITIAL_GAIN_LEVEL = 267 H

Format: VAR

Data: 1st word: Red odd camera value
2nd word: Red even camera value
3rd word: Green odd camera value
4th word: Green even camera value
5th word: Blue odd camera value
6th word: Blue even camera value
7th word: Rear red odd camera value
8th word: Rear red even camera value
9th word: Rear green odd camera value
10th word: Rear green even camera value
11th word: Rear blue odd camera value
12th word: Rear blue even camera value

Values: 0 H – 3FF H (16 bit unsigned)

7.37 Update initial gain level

With this tag the initial gain values are updated with the actual gain values. The actual gain values are changed by internal gain control. This tag is meant to store a leveled operation point to the startup values of the setting.

TAG-ID: TAG_UPDATA_INITIAL_GAIN = 268 H

Format: Bin

Data: 1: initial values are updated

Default: 0

7.38 Set maximum number of scan lines

Set the maximum number of scan lines generated after start scan condition is true. With this Tag it is possible to limit the necessary size of memory for the image.

With TAG_STOP_BY_MAX_NUMBER_SCANLINES the mode for further operation at reaching maximum number is determined.

TAG-ID: TAG_SET_MAX_NUMBER_SCANLINES = 271 H

Format: Short

Data: Maximum number of scan lines

Default: 0

7.39 Stop at max number of scan lines

With tag the mode for further operation after reaching maximum number of scan lines is determined.

TAG-ID: TAG_STOP_BY_MAX_NUMBER_SCANLINES = 272 H

Format: Bin

Data: 0: Scan Process continues after over size detection
1: An error message is generated

Default: 0

7.40 Set additional paper length

When automatic detection of image length is active (TAG_SET_SCANCONDITION = 2) with this TAG the number of lines **after** end of trigger signal is determined.

TAG-ID: TAG_SET_VSY_OVERSIZE = 273 H

Format: Short

Data: Length of paper oversize in number of lines

Default: 0

7.41 Encoder parameter

This Tag configures the parameter of the encoder. Using encoder mode adapts camera speed to varying scan speeds in transport direction.

TAG-ID: TAG_SYNCMODE_EXTENDED = 279 H

Format: VAR

Bit	15	0	
	Encoder resolution in nm / step	(low word) (high word)	Word 1 Word 2
	Number of values for averaging		Word 3
	Modes		Word 4
	reserved		Word 5
	Number of Encoder Channels		Word 6

Number of values for averaging:


- 0: No average
- 1: average with 2 values
- 2: average with 4 values
- 3: average with 8 values
- 4: average with 16 values
- 5: average with 32 values
- 6: average with 64 values

Modes: 0: encoder mode inactive
1: Continues update using average
5: Line Trigger Mode


Number of Encoder Channels:
0: encoder resolution is distance between the positive edges

- 1: 1 Channel Encoder (2 edges per step)
- 2: 2 Channel Encoder (4 edges per step)


EncoderMode = 0



EncoderMode = 1



EncoderMode = 2



Note:

Because most available industrial encoders have jitter between rising and falling edges of each channel and also have jitter between the two channels best results are with using “Number of Encoder Channels” = 0.

7.42 Setting Verify ID

The configured settings can be labeled together with a comment with this tag. A checksum calculated over the configuration can be used as a signature to check the validity of the selected settings.

TAG-ID: TAG_SETTING_VERIFY = 27C H

Format: VAR

Data:
Bit

15	0	
SettingID		Word 1
Version		Word 2
Description Text (40 Chars)		Word 3
...		
Setting Signature		Word 23
MarkSettingBits0 (low)		Word 24
MarkSettingBits1 (high)		Word 25

Setting ID: An arbitrary ID to identify a defined set of settings loaded with order MK.

Version: Version of TAG Definition, default 0

Description Text: Comment text with 0 as last value

Setting Signature:

A unique number calculated from setting parameters of selected settings. Some TAGs which are usually device specific are not included in this calculation. These Tags are:

- TAG_SET_GAIN (1C0 H)
- TAG_SET_POINT_WHITE_REFERENCE (1C2 H)
- TAG_SET_GAIN_WARN_LEVEL (1C4 H)
- TAG_SET_MINIMUM_GAIN_LEVEL (1C5)
- TAG_SET_INITIAL_GAIN_LEVEL (267 H)
- TAG_SET_LED_START_DUTYCYCLE (311 H, also “Start Duty Cycle” in Tag 310H)
- TAG_CURRENT_LED_DUTYCYCLE (312H)

TAG_SET_VSYSTART (230 H)
 TAG_SYNCMODE_EXTENDED->EncoderResolution

MarkSettingBits0: Corresponded Bit select Setting 0 ... 15 for check (mark with '1' to select/ '0' to deselect)

MarkSettingBits1: Corresponded Bit select Setting 16 ... 19 for check (mark with '1' to select/ '0' to deselect)

7.43 Select reference data set for black level correction

This tag selected the reference data set for black level correction. The data set must be stored before with order DS.

TAG_ID: TAG_SEL_REFRENCEDATA_BLACK (280 H)
 Format: Short
 Data: 0: Black Reference data set 1 is used
 1: Black Reference data set 2 is used
 2: Black Reference data set 3 is used (camera P1.40 and higher)
 3: Black Reference data set 4 is used
 Default: 0

7.44 Select reference data set for white level correction

This tag selected the reference data set for shading correction. The data set must be stored before with order DS.

TAG_ID: TAG_SEL_REFRENCEDATA_WHITE (281 H)
 Format: Short
 Data: 0: White Reference data set 1 is used
 1: White Reference data set 2 is used
 2: Black Reference data set 3 is used (camera P1.40 and higher)
 3: Black Reference data set 4 is used
 Default: 0

7.45 Set number of white reference samples for average

If scan light is overlaid with flicker effects or the amount of noise is high than it is useful to average subsequent white reference data samples before the data are used to calculate new gain values. Using this average mode slows the speed of gain control. But this is only significant if the light can change rapid.

TAG_ID: TAG_SET_WHITEREF_AVERAGE (283 H)
 Format: Short
 Data: 0 : No average is done
 1 : 2 Samples are used
 2 : 4 Samples are used
 3 : 8 Samples are used
 4 : 16 Samples are used
 5 : 32 Samples are used
 Default: 0

7.46 Select mode for white reference

This tag determines at which position the reference data for gain control a captured.

TAG-ID: TAG_SEL_WHITEREFPOS (287 H)

Format: Short

Data: 0 : Front tab data is used for gain control, Rear channels follows (slave rear)
 1 : Rear tab data is used for gain control, front channels follow (slave front)
 2 : Front and Rear TAP data are controlled independently
 3 : Automatic master detection. If white reference position is located in front TAP than front is master. If white reference position is located in rear TAP than rear is master.

In case of 0, 1 or 3 the difference of initial gain values between corresponding front and rear channels is build and added to gain of the following side (= slave side). If initial gain is set to zero the same gain values are used for the slave side.

Default: 0

7.47 Select insert information to video data

This TAG defines the debug and test data which is inserted to video data stream. The debug data overwrites image data values of the image.

TAG-ID: TAG_SET_INSERT_MODE (293 H) (allPixa with packet 1.3 and higher)

Format: Short

Data: Bit encoded, see table below

Bit No	Name	Position in image	Data length	Hint
0	FirstLine_InfoBlock	First line Pixel No. 0 bis 22	23 Px	Refer bellow
1	LastLine_TestRamp	Complete last line	Complete line	Start value: 128
2	LastLine_IMG_ChkSum	Middle of the last line	2 Pixel for each Tap	Refer bellow
3	EachLine_Infoblock	Each line Pixel No. 1 to 8	8 Pixel	Refer bellow
4:5	EachLine_GreyValSum OrContrast	Each line Pixel No. 10 to 15	6 Pixel	0: Inactive 1: EachLine_GreyValSum 2: Inactive 3: EachLine_ContrastVal
6..15	Reserved	--	--	For future use

Bit No 0: first line info block

Pixel line	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	n-1
0	SerialNumber					ImgCnt			IntTime			LineTime			EnClks			Error	TimeStamp			Video		

Bit No 1: Last line test ramp

Pixel line	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	n-1
...	Vid	Vid	Vid	Vid	Vid	Vid	Vid	Vid	Vid	Vid	Vid	Vid	Vid	Vid	Vid	Vid	Vid	Vid	Vid	Vid	Vid	Vid	Vid	Vid
...	Vid	Vid	Vid	Vid	Vid	Vid	Vid	Vid	Vid	Vid	Vid	Vid	Vid	Vid	Vid	Vid	Vid	Vid	Vid	Vid	Vid	Vid	Vid	Vid
...	Vid	Vid	Vid	Vid	Vid	Vid	Vid	Vid	Vid	Vid	Vid	Vid	Vid	Vid	Vid	Vid	Vid	Vid	Vid	Vid	Vid	Vid	Vid	Vid
...	Vid	Vid	Vid	Vid	Vid	Vid	Vid	Vid	Vid	Vid	Vid	Vid	Vid	Vid	Vid	Vid	Vid	Vid	Vid	Vid	Vid	Vid	Vid	Vid
LastLine	128	129	130	131	132	133	134	135	136	137	138	139	140	141	142	143	144	145	146	147	148	149	...	m

Bit No 2: Last line image check sum

Pixel	0	1	2	...	n-3	n-2	n-1
line							
...	Vid	Vid	Vid	...	Vid		
LastLine R	Vid	Vid	Vid	...	Vid	ChkSumRed(15:8)	ChkSumRed(17:0)
LastLine G	Vid	Vid	Vid	...	Vid	ChkSumGreen(15:8)	ChkSumGreen(17:0)
LastLine B	Vid	Vid	Vid	...	Vid	ChkSumBlue(15:8)	ChkSumBlue(17:0)

Bit 3-5: Each line Info block

Pixel	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
value	Infoblock										GreyValSum or ContrastValue							
R	xFF	Error Reg	Speed 2High Line Time (19:16)	Enc Clks (23:16)	Next LTPos Int (15:8)	Time Stamp (23:16)	Max Val Front (7:0)	Max Val Rear (7:0)	Res (vid)	xFF	Red Front (23:16)	Green Front (23:16)	Blue Front (23:16)	Red Rear (23:16)	Green Rear (23:16)	Blue Rear (23:16)	xFF	Vid
G	x00	Line CNT (15:8)	Line Time (15:8)	Enc Clks (15:8)	Next LTPos Int (7:0)	Time Stamp (15:8)	Max Val Front (7:0)	Max Val Rear (7:0)	Res (Vid)	x00	Red Front (15:8)	Green Front (15:8)	Blue Front (15:8)	Red Rear (15:8)	Green Rear (15:8)	Blue Rear (15:8)	x00	Vid
B	X00	Line CNT (7:0)	Line Time (7:0)	Enc Clks (7:0)	Next LTPos Fract (7:0)	Time Stamp (7:0)	Max Val Front (7:0)	Max Val Rear (7:0)	Res (vid)	X00	Red Front (7:0)	Green Front (7:0)	Blue Front (7:0)	Red Rear (7:0)	Green Rear (7:0)	Blue Rear (7:0)	X00	Vid

Note:

Type and position of information for each line is specified with TAG_COLUMN_INSERTMODE (2B0 H)

7.48 Color channel for MuxOutCol

With this TAG image color can be configured for the RGB channels at the output to camera link cable.

TAG-ID: TAG_MUX_OUT_COLOR_SELECT = 295H

Format: SHORT

Data: Selects the color channel for the Output MUX.

Bits 5:4	Output Channel 1	Bits 3:2	Output Channel 2	Bits 1:0	Output Channel 3
0 (Default)	Red	0 (Default)	Green	0 (Default)	Blue
1	Red	1	Red	1	Red
2	Green	2	Green	2	Green
3	Blue	3	Blue	3	Blue

7.49 Change Red / Blue color channel

With this tag red and blue color channel are exchanged at the output to CameraLink.

TAG-ID: TAG_R_B_CHANGE = 296H

Format: BIN

Data: 0: keep red and blue order
1: Exchange red and blue channel

7.50 Enable camera link high speed

This Tag enables a higher transfer clock on the camera link interface for increasing data rate. Refer to Camera Link specification regarding cable length and transfer clock.

TAG-ID: TAG_ENABLE_CL_HIGHSPEED (297H)

Format: BIN
 Data: 0 = Camera Link frequency 72,86 MHz (Standard speed)
 1 = Camera Link frequency 85 MHz (High speed)
 Default: 0

*1) Hint: KA8-allPixa supported within packet1.2 and lower. For packet 1.3 and higher refer to tag 0x2BC!

7.51 Horizontal binning

This tag enables horizontal pixel reduction. Several neighbored pixel are averaged to one single pixel which is output.

TAG-ID: TAG_SET_BINNING = 29A H
 Format: SHORT
 Values 0: binning is off

Value	Reduction
0	1/1 (no reduction)
1	1/2
2	1/4
3	1/8
4	1/16

Note:
 HsyLength is not affected by this parameter.

7.52 Set register parameter to setting

Values sent with this tag can be stored to the actual active setting.

TAG-ID: TAG_REGISTER_TO_SETTING = 29D H
 Format: VAR
 Data: Address und Data for Register

Bit	15	0	
	Address 1		Word 1
	Data word 1 to write in Register with Address 1		Word 2
	Address 2		Word 3
	Data word 2 to write in Register with Address 2		Word 4
	Address 3		Word 5
	Data word 3 to write in Register with Address 3		Word 6
	Address 4		Word 7
	Data word 4 to write in Register with Address 4		Word 8

Not used entries must be set to 0.

7.53 Set first pixel of white reference area relative to image window

This tag defines the position for the white reference in scan line direction relative to the actual image window; that means relative to TAG_SET_HSYSTART (232H)

TAG-ID: TAG_SET_HORIZONTAL_WREF_START =2A1H
 Format: Short

Data: Position of first Pixel or Column for white reference
Position 0 is the first pixel of the active scan window defined by TAG_SET_HSYSTART.
Negative values in 2' complement are used to position the window left of the active scan window.

Default values: 0

7.54 Set first scan line of white reference area in transport direction

This tag defines the first scan line used for white reference area in transport direction.

Position = 0 is the first scan line after start of the active scan window defined by TAG_SET_VSYSTART.

Negative values in 2' complement are used to set the position before of the active scan window.
The first possible line is the line captured after frame trigger defined by TAG_SET_SCANPATTERN.
Therefore the maximum negative value can be equal to value set by TAG_SET_VSYSTART.

TAG-ID: TAG_SET_VERTICAL_WREF_START = 2A3H

Format: SHORT

Data: Line start position of white reference area relative to TAG_SET_VSYSTART.
-(TAG_SET_VSYSTART) (TAG_SET_VSYLENGTH)

Default value: 0

7.55 Set number of lines for white reference area

This tag defines the number of lines used for white reference area in transport direction.

TAG-ID: TAG_SET_VERTICAL_WREF_LENGTH = 2A4 H

Format: SHORT

Data: 2..1022; Only even values are supported!

Default: 2

7.56 Set value for stop gain control

If video level of white references tropes below a certain factor the automatic gain control can be stopped.
This operation mode is activated by Bit 4 of TAG_SET_WHITECONTROL_MODE (318 H).

This tag sets the value to disable gain control if the current channel values for the white reference different to the mean of all set point white values (1C2H).

The threshold for disable gain control is defined by:

Sum of all actual channel values < (value / 1024) * mean of all set point white values

Example:

All desired value for white reference (1C2 H) are set to 800

TAG_SET_GAIN_STOP_FACTOR = 512

If sum of all actual white references tropes below (512 / 1024) * 800 = 400, then automatic gain control is disabled.

TAG-ID: TAG_SET_GAIN_STOP_FACTOR = 2A5H

Format: Short

Data: 0 ... 1000

7.57 Set White Reference visible mode

This tag selects the type of visibility of the borders of the white reference area. The borders are visible if TAG_SHOW_WHITEREF_BORDERS (226H) is set.

Note:

The visible mode should be disabled for capturing images for offset and shading correction.

TAG-ID: TAG_SET_WREF_VISIBLE_MODE = 2A6H

Format: Short

Data: 0: Show Borders of White Reference Area
2: Show Border Lines of White Reference Area

Default: 0: Show Borders of White Reference Area

7.58 Clear Setting content

With this tag the selected setting of the camera is erased in the non-volatile memory.

TAG-ID: TAG_SETTING_CLEAR = 2A7 H

Format: SHORT

Data: 1 - 19: Number of selected setting to clear
With all other values the tag is ignored

7.59 Use absolute position of white reference in CCD direction

This tag determines if first pixel of white reference position is defined absolute or relative to scan window.

TAG-ID: TAG_USE_HORIZONTAL_WREF_START_ABSOLUTE =2A9H

Format: BIN

Data: 1: first pixel of position for white reference is defined absolute with TAG_SET_HORIZONTAL_POSWREF_ABSOLUTE (223H).
0: first pixel for position of white reference is defined relative to the active scan window with TAG_SET_HORIZONTAL_WREF_START (2A1H).

Default values: 0

7.60 Select position for insert information

TAG determines if information for first or / and last line is inserted to image.
The kind of information for first and last line is determined with TAG_SET_INSERT_MODE (293 H).

TAG-ID: TAG_COLUMN_INSERTMODE (2B0 H)

Format: Short

Data: Bit encoded, see description below
0: Information data inserted to the first pixel of scanline
1: Information data inserted to the last pixel of scanline
2: Information data inserted to the first and last pixel of scanline
All other values invalid

Default: 0:

7.61 Enable Line period at free run (Shutter Mode at Free run)

This Tag enables/ disables the functional shutter mode. The value for the line period is set with

TAG_SET_LINEPERIOD = 2B7 H.

If the integration time is out of range corresponding to the line scan time an error message is provided and the tag will not be processed.

TAG-ID: TAG_USE_LINEPERIOD = 2B6 H
 Format: Short
 Data: 0: Disable shutter mode at free run
 1 ... 65535: Enable shutter mode at free run
 Default: 0: Disable shutter mode at free run

7.62 Set Line period at free run (Shutter Mode at free run)

This Tag set the time for the scan line period. The line period is used together with the integration time (TAG_SET_INTEGRATION_TIME_IN_NS = 24A H). If the integration time is out of range corresponding to the line scan time an error message is provided and the tag will not be processed.

TAG-ID: TAG_SET_LINEPERIOD = 2B7 H
 Format: long
 Data: Time for line period in ns
 Range: Min value > Integration time in ns (Tag x24A)
 Max value < 12337000
 Default: 0

7.63 Enable Keystone correction

This Tag enables/ disables the keystone correction function. The parameter for the keystone correction are set with the Tag "TAG_SET_KEYSTONECORRECTION = 2B9 H". If the parameters are invalid an error message is provided and the tag will not be processed.

TAG-ID: TAG_USE_KEYSTONECORRECTION = 2B8 H
 Format: Short
 Data: 0 : Disable keystone correction
 1..65535 : Enable keystone correction
 Default: 0 : Disable keystone correction

7.64 Parameters for Keystone correction

This Tag configures the parameter of the keystone correction. The first parameter is the shift for the correction on the edge of the image in Pixel. The sign of the value defines the correction for the red channel. Positive values for zoom in and negative values for zoom out (for the blue channel vice versa). The second parameter defines the position of the zero crossing. For the common keystone correction the position is in the middle of the image (scan line length/2). For special use (e.g. simple TCA correction) the position can be shifted starting from the center up to the edge of the image.

TAG-ID: TAG_SET_KEYSTONECORRECTION = 2B9 H
 Format: VAR

Data:

15	0
Pixel shift for correction	Word 1
Position of zero crossing	Word 2

Pixel shift for correction (Word 1):
 Format is short
 Data range from +40 to -40 [Pixel/10]
 All other values invalid
 Default value is 0

Position of zero crossing, offset starting from center (Word 2):
 Data range from 1 to value of scan line length/2 [Pixel]
 All other values are invalid
 Default is [value of scan line length/2]

7.65 Select data set for color conversion method

This tag is used to select the CCM data set. Four different sets can be stored in the non-volatile memory of the camera. For transfer to camera command DD is used.

TAG_ID: TAG_SEL_CCM (2BB H)
 Format: Short
 Data: 0: CCM data set 0 is used
 1: CCM data set 1 is used
 2: CCM data set 2 is used
 3: CCM data set 3 is used
 Default: 0: CCM data set 0 is used

7.66 Select the camera link transfer speed

This Tag enables a higher transfer clock on the camera link interface for increasing data rate. Refer to Camera Link specification regarding cable length and transfer clock. Check environment and application for selection. The "Reduced speed" is used for long cable application.

TAG-ID: TAG_SELECT_CL_SPEED (2BC H)
 Format: Short
 Data: 0 = Camera Link frequency 72,86 MHz (Standard speed)
 1 = Camera Link frequency 85 MHz (High speed)
 2 = Camera Link frequency 63,75 MHz (Reduced speed)
 All other values invalid
 Default: 0

Hint:

allPIXA supported with packet 1.3 and higher. For packet 1.2 and lower old tag 0x297 is used.

7.67 Set weights for the color channels

TAG-ID: TAG_SET_COLOR_WEIGHTS = 305 H
 Format: VAR

Data:

Bit	15	0	
	Weight for Red Channel		Word 1
	Weight for Green Channel		Word 2
	Weight for Blue Channel		Word 3

The weights has to be multiplied with factor 100

Example:

For weight 0.6 the needed value is 60

For Grey or Interleave output the sum of the weights should be 100.

Default: Red=30
 Green = 59
 Blue = 11

See also: TAG_SET_GREYOUTPUT_MODE (322 H)

7.68 Set reduction mode in transport direction

With this TAG image is reduced in vertical direction by suppressing scan lines.

TAG-ID: TAG_SET_SUPPRESSED_LINES = 30E H
 Format: SHORT

Data: number of suppressed lines
 Range: 0 ... 255

Default: 0

The resulting reduction factor is: 1 + number of suppressed lines

7.69 Set trace mask

With this tag the information internally traced in the camera is specified.

Note: High amount of internal tracing data will decrease micro controller performance. Do only use for test purpose.

TAG-ID: TAG_SET_TRACE_MASK = 0x30F
 Format: SHORT

Data: Bitmap for the selection of different trace items
 Bit 0 General debug information
 Bit 1 Communication transport layer
 Bit 2 Communication transport layer details
 Bit 3 reserved
 Bit 4 State Trace White- and Led Control
 Bit 5 internal states
 Bit 6 image
 Bit 7 environment values
 Bit 8 .. 15 reserved

Default: 0

7.70 Modify Video level with brightness and contrast control

With this tag brightness and contrast level are changed by additional offset and gain parameters.

TAG-ID: TAG_VIDEOLEVEL_CORRECTION = 315 H
 Format: VAR

Data:

Change brightness and contrast level by additional offset and gain parameters

Bit	15 0	
	Mode	Word 1
	Additional Offset Red	Word 2
	Additional Offset Green	Word 3
	Additional Offset Blue	Word 4
	Additional Gain Factor Red	Word 5
	Additional Gain Factor Green	Word 6
	Additional Gain Factor Blue	Word 7

Mode: 0: Do not use this features
 1: Use Offset and Gain Correction

Additional Offset *color*:
 $VideoOut = VideoIn + Additional\ Offset$
 Range: - 255... 255 (in 10 bit Video Range)
 Default: 0

Additional Gain Factor *color*:
 $VideoOut = VideoIn * Additional\ Gain\ Factor / 1000$
 Range: 0 ... 2000
 Default: 1000

7.71 Master-Slave-Control

Several cameras can be connected to Master/Slave mode. By this master camera serves line valid und frame valid for the slave cameras.

With this tag it is configured how the camera determines to be master or slave.

TAG-ID: TAG_MASTER_SLAVE_CONFIGURATION = 317 H

Format: SHORT

Data: Refer description bellow

value	Mode	Meaning
0	NoMasterSlave (Default)	Camera is master, master / slave interface is inactive, signals are tri-state
1	Master Mode 0	Camera is master, master / slave interface is active (output)
2	Slave Mode 0	Camera is slave, master / slave interface is active (input)
3	AutoSelect Mode 0	Input nSelMaster determines master or slave 0: KA is master 1: KA is slave Default via Pull-Up, avoid short circuit at M/S interface

7.72 Set white Control mode

Parameter sets the mode of white control.

TAG-ID: TAG_SET_WHITECONTROL_MODE =318H

Format: SHORT

Data: Bit 0: Gain Control using area range mode defined with the following tags:

TAG_SET_HORIZONTAL_POSWREF_ABSOLUTE	(223 H)
TAG_SET_HORIZONTAL_WREF_LENGTH	(224 H)
TAG_SET_WHITEREF_AVERAGE	(283 H)
TAG_SEL_WHITEREFPOS	(287 H)
TAG_SET_HORIZONTAL_WREF_START	(2A1 H)
TAG_SET_VERTICAL_WREF_LENGTH	(2A4 H)

Bit 1: reserved
 Bit 2: reserved
 Bit 3: Use sync mode/ Taking references is synchronized with area scan. Additional the following TAGs are used for position of reference area in vertical direction:
 TAG_SET_VERTICAL_WREF_START (2A3 H)

Bit 4: stop gain control if the current level is below a defined factor.
 The value for factor is set by TAG_SET_GAIN_STOP_FACTOR (2A5H).

Bit 5: Internal use, set to '0'
 Bit 6 ...15: Currently not used set 0

Default: 0

7.73 RGB line distance between the color lines of a tri-linear sensor

Number of line shifts to compensate the geometric distance between the color lines of a tri-linear sensor. Sub-line shift is available.

TAG-ID: TAG_SET_RGB_LINEDISTANCE = 319 H
 Format: Short

Data: Distance in units of 1/1024 line distances for delay red to green and blue green

Range 0 ... 4096 (sensor length greater than 4096 pixel)
 0 ... 6144 (sensor length less than 4096 pixel)

Example:

Shift of 4 lines: 4 * 1024 = 4096

Shift of 1,5 lines: 1,5 * 1024 = 1536

7.74 Set grey video out mode

TAG-ID: TAG_SET_GREYOUTPUT_MODE (322 H)
 Format: SHORT

Data	
0	Disabled (normal RGB Output), CL-Dual Base
1	2*8 bit grey according camera link specification on first CL-port
2	2*10 bit grey according camera link specification on first CL-port
3	2*12 bit grey according camera link specification on first CL-port
4	reserved
5	reserved
6	2*8 bit grey according camera link specification on both CL-ports at CL-Dual-Base
7	2*10 bit grey according camera link specification on both CL-ports at CL-Dual-Base
8	2*12 bit grey according camera link specification

	on both CL-ports at CL-Dual-Base
else	reserved

The weight for color to grey conversion is defined by TAG_SET_COLOR_WEIGHTS (305 H).

7.75 Set value for test pattern

The value is used to set the static output of some test patterns in combination with TAG_SET_TESTPATTERN_MODE (222 H).

TAG-ID: TAG_SET_TESTPATTERN_LEVEL = 323H

Format: Short

Data: 0 ... 1023

Default: 0

7.76 Set Gain in the pre amplifier stage

Set the CDS Gain value in amplifier of ADC (analog digital converter)

TAG-ID: TAG_SET_CDS_GAIN = 3A0H

Format: VAR

Data: 1st word: Red CDS gain value
 2nd word: Green CDS gain value
 3rd word: Blue CDS gain value
 4th word: Rear red CDS gain value
 5th word: Rear green CDS value
 6th word: Rear blue CDS value

Values: 0: - 3 dB
 1: 0 dB
 2: +3dB
 3: +6 dB

All other values ignored

Default: 0

7.77 Select Type of Camera Link Interface

With this tag the type of camera link is selected.

TAG-ID: TAG_SET_CAMERALINK_INTERFACE = 3A1 H

Format: SHORT

Values: 0= Camera Link Base
 1= Camera Link Medium
 2= Camera Link Full (currently not supported)
 All other values invalid

Default 0= Camera Link Base

7.78 Set External Signal Assignment

This Tag is used for the IO configuration. For easy configuration use the IO Configurator in the CST software tool.
 (For allPIXa user, refer to the allPIXa user manual).

TAG-ID: TAG_SET_EXTERNAL_SIGNAL_ASSIGNMENT = 701 H

Format: VAR

Data: List of Assignments to configuration description in Order DV

Define the assignment

Bit	15	Word 1	
	0		Word 2
	Function Index 1 Selector 1		...

...	Function Index n Selector n	Word 59 Word 60	

Function Index: ASCII Character: A.. ..Z or AA.. ..ZZ for output functions
a.. ..Z or aa.. ..zz for input functions
aA.. ..zZ for bidir functions

At function indices with one digit the ASCII character must be set in the low byte of the corresponding WORD. The high byte must be set to 0.

Example: "a" -> 0x0061

At function indices with two digit the first ASCII character must be set to the low, the second character to the high byte of the corresponding WORD.

Example: "Ab" -> 0x6241

Input selector: Binary value 0 ... 255

Maximum number of entries is 30. Unused entries must be set to 0. A 0 entry in function index is used to mark the end of list.

Because the pk-response has a static format the list is longer as the number of used entries.

Assign an input port selected with "Input Selector " to function defined by "Function Index"

Table of assigned input function indices:

LS0	"a"		
LS1	"b"		
LS2	"c"		
LS3	"d"		
Fast start	"e"		
Inkr0	"f"		
Inkr1	"g"		
nLineSync	"h"		
nFrameSync	"i"		
Autoselect	"j"		
Format impulse Count	"k"		
Format impulse Reset	"l"		
GP_IO_IN0	"m"		

GP_IO_IN1	"n"		
GP_IO_IN2	"o"		
GP_IO_IN3	"p"		
GP_IO_IN4	"q"		
GP_IO_IN5	"r"		
GP_IO_IN6	"s"		
GP_IO_IN7	"t"		
(for internal use)	"v"		

Table of assigned output function indices:

VSY-Signal	A	
HSY-Signal	B	
LED-PWM	C	
RS232_Activate	D	
SEL_GP_IO_OUT0	E	Select IO Pin
SEL_GP_IO_OUT1	F	Select IO Pin
SEL_GP_IO_OUT2	G	Select IO Pin
SEL_GP_IO_OUT3	H	Select IO Pin
SEL_GP_IO_OUT4	I	Select IO Pin
SEL_GP_IO_OUT5	J	Select IO Pin
SEL_GP_IO_OUT6	K	Select IO Pin
SEL_GP_IO_OUT7	L	Select IO Pin
FUNC_GP_IO_OUT0	M	Select Function for GP_IO
FUNC_GP_IO_OUT1	N	Select Function for GP_IO
FUNC_GP_IO_OUT2	O	Select Function for GP_IO
FUNC_GP_IO_OUT3	P	Select Function for GP_IO
FUNC_GP_IO_OUT4	Q	Select Function for GP_IO
FUNC_GP_IO_OUT5	R	Select Function for GP_IO
FUNC_GP_IO_OUT6	S	Select Function for GP_IO
FUNC_GP_IO_OUT7	T	Select Function for GP_IO

Table of assigned bi-directional function indices:

MS-Interface	Aa	2 Wire Master-Slave-Interface
SMC	Bb	4 Wire SMC Interface

7.79 Use an assignment table from another setting

Every setting data set stored in the non-volatile memory carries its own assignment table. If the assignment table of another setting should be used the reference setting number is defined with this TAG. Then the assignment table of the referenced setting is used.

TAG-ID: TAG_SET_EXTERNAL_SIGNAL_ASSIGNMENT_REFERENCE = 702 H

Format: SHORT

Data: Reference Setting Number
 0: Use setting table of current setting
 1 ... 19: Use setting table of another setting

Reference settings are only settings with does not itself references to other settings.

7.80 Format of the Response mk

15	8	7	0	
m		k		0 Name
Low word length				2 Length
High word length				4 Length

Sender		6	Sender
Reserved	reserved	8	Receiver
1. Data word from read register			
....			
n. Data word from read register			
Checksum		10	Check sum

The **mk** response contains only data if a read-register-offset is send in Command MK.

8. MS: Maintenance Sensors

The Command MS return the status of the camera sensors and the status of external inputs.

15	8	7	0	
M		S		0 Name
Low word length				2 Length
High word length				4 Length
Reserved		Reserved		6 Sender
Reserved		Reserved		8 Receiver
reserved				10
REQUEST_CONTAINER (optional)				12
Check sum				Check sum

REQUEST_CONTAINER: Certain TAG_IDs

Using this filed a certain container can requested.
List of supported Containers:

- TAG_ENVIRONMENT_VALUES = 292H

The parameters are structured as tags.

8.1 Format of the Response ms

15	8	7	0	
m		s		0 Name
Low word length				2 Length
High word length				4 Length
Sender				6 Sender
Reserved		Reserved		8 Receiver
TAG 1				
..				
TAG n				
Checksum				10 Check sum

The **ms** response parameters are structured as tags.

TAGs for ms response

8.2 Environment Values

TAG-ID: TAG_ENVIRONMENT_VALUES =292H

Format: CONT

It can contain following TAGs:

TAG-ID: TAG_HWMONITOR_VOLTAGE_VANALOG1 (370H)
Format: SHORT
Data: Internal voltage 1 in mV

TAG-ID: TAG_HWMONITOR_VOLTAGE_VANALOG2 (371H)
Format: SHORT
Data: Internal voltage 2 in mV

TAG-ID: TAG_HWMONITOR_VOLTAGE_VCORE (372H)
Format: SHORT

Data Internal voltage 3 in mV

TAG-ID: TAG_HWMONITOR_VOLTAGE_SUPPLY1 (373H)
 Format: SHORT
 Data Internal voltage 4 in mV

TAG-ID: TAG_HWMONITOR_VOLTAGE_SUPPLY2 (374H)
 Format: SHORT
 Data Internal voltage 5 in mV

TAG-ID: TAG_HWMONITOR_VOLTAGE_SUPPLY_CCD (376H)
 Format: SHORT
 Data Internal voltage 6 in mV

TAG-ID: TAG_HWMONITOR_VOLTAGE_IN (377H)
 Format: SHORT
 Data External in voltage in mV

TAG_HWMONITOR_TEMPERATURE_BOARD (381H)
 Format: SHORT
 Data Temperature of internal board°C

TAG_HWMONITOR_TEMPERATURE_SENS (382H)
 Format: SHORT
 Data Temperature of sensor °C

8.3 Common values

Free TAGs (not part of a Container TAGs):

TAG_STATE_EXT_INPUT	= 245 H	(see Command PK)
TAG_ACTUAL_WHITE_REFERENCE	= 1C3 H	(see Command PK)
TAG_GET_SYNCINTEGRATION_TIME	= 290 H	
TAG_IMAGECOUNTER	= 291 H	
TAG_BETRIEBSZUSTAND	= 103 H	(see Command PK)
TAG_SET_GAIN	= 1C0 H	(see Command MK)
TAG_ERROR	= 1CA H	(see Command PK)
TAG_STATUS	= 1CB H	(see Command PK)
TAG_GET_MASTERSLAVE_MODE	= 2B5 H	
TAG_GET_TRANSPORT_SPEED	= 393 H	

Integration time in Nanoseconds

TAG-ID: TAG_GET_SYNCINTEGRATION_TIME =290 H
 Format: LONG
 Data: Time per line in Nanoseconds

The integration time calculated from external sync source in variable encoder mode is returned. If this mode is not used the returned value is 0.

Actual internal image counter

TAG-ID: TAG_IMAGECOUNTER = 291 H
 Format: SHORT
 Data: actual value of internal image counter

Get Current Master/Slave Mode

TAG_ID: TAG_GET_MASTERSLAVE_MODE (2B5 H)

Format: Short

0: No Master Slave Mode is defined
1: Camera is Master
2: Camera is Slave

Current transport speed

TAG-ID: TAG_GET_TRANSPORT_SPEED (393 H)

Format: SHORT

Data: transport speed in mm/sec

special values are:

0xffffd: no data available

0xffffe: Speed too low

0xfffff: Speed too high (only detectable using dynamic speed adaptation mode)

Shows current speed mode as a feature of dynamic speed adaptation mode

The transport speed is calculated from external sync source in variable encoder mode.
For calculation the TAG_PHYS_AUFL_VERT (244H) is used and must set right.

If this mode is not used the returned value is 0.

9. MR: Take Reference

The MR Command is used to create a white or black level reference internally. This reference data are stored in non volatile memory.

With the black level reference data the camera board corrects the offset failure. With the white reference data the shading effect is corrected.

Before sending the command all image processing functions must be disabled (e.g. using of Tag x91b). Also the scan condition for the reference must be set (free run/ encoder mode).

After sending the command to the camera the data are collected internally depending on the scan condition. Within the command the type of reference (Offset/ Shading) is selected and also the Id for the data set.

A time out value ensures that the command is aborted in case of missing scan condition.

Format of the Command MR

15 8 7 0

M		R		0 Name
Low word length				2 Length
High word length				4 Length
reserved		reserved		6 Sender
reserved		reserved		8 Receiver
Reserved				10
ABGLTYP				12 see below
TYPREF				14 see below
UseSettingNo				16 see below
RefNo				18 see below
Time Out				20 see below
Check sum				22 Check sum

ABGLTYP = 0 (Reserved, not used for allPixa)

TYPREF = Select type of reference
 0 Create black level reference
 1 Create white level reference
 All other values invalid

UseSettingNo= =0 (Reserved, not used for KA8)

RefNo = ID number for Data Set
 0 Data set No.1
 1 Data set No.2
 2 Data set No.3
 3 Data set No.4
 All other values invalid

Time Out = Time out value in seconds, Maximum time for processing the command. After reaching the Time Out value the command is aborted with an error message.
 0..65565 value in [sec]

Format of the Response mr

The **mr** response has no specific data (see 1.4.2. General statement on responses).

10. WR: Check White Control Status

The WR Command is used to check the current white balance status.

The white status is ok when three successive times the control error is smaller than a predefined value and the gain value does not exceed the set gain warn level. If white status is not ok a fe-response is generated.

Format of the Command WR

15	8	7	0	
W		R		0 Name
Low word length				2 Length
High word length				4 Length
Reserved		Reserved		6 Sender
Reserved		Reserved		8 Receiver
reserved				10
WhiteOkCriteria				(12) optional , see Extended WR
Check sum				12(14) Check sum

Extended format of the Command WR

An additional parameter in the WR command can be used to adjust the sensitivity of the detection of the controlled state. A **WhiteOkCriteria** of 3 causes the WR command to wait for 3 control cycles without adjusting gain like the standard WR command. A value of one requires just one cycle without controlling.

Four error conditions are possible and reported in a fe-response

1. The desired output values could not be reached (Timeout) (error code = 0xF7)
2. The maximum warning level is reached (error code = 0xF6)
3. The minimum gain level is exceeded (error code = 0x41)

Format of the Response wr

The **wr** response has no specific data (see 1.4.2. General statement on responses).

11. TA: Tap Adjustment

The TA Command is used to adjust the sensor tab border.

If tab adjustment failed a fe-response is generated.

11.1 Format of the Command TA

15	T	8	7	A	0	
	Low word length					0 Name
	High word length					2 Length
	Reserved			Reserved		4 Length
	Reserved			Reserved		6 Sender
						8 Receiver
						10
	Check sum					12 Check sum

Four error conditions are possible and reported in a fe-response

1. Timeout (error code = 0x6E)
2. other adjustment error (error code = 0x6F)

11.2 Format of the Response ta

The **ta** response has no specific data (see 1.4.2. General statement on responses).

12. PA: Parameters for all Units

The PA Command is used for setting the essential operating modes. The Command is distributed within the device to all units of the device.

The actual parameters are structured as tags.

Note:

Indeed, the number of PA Commands is not limited, but it is also permissible to pack many parameters into one PA Command, whereby, nevertheless, the maximum allowable length of the Command must be taken into account.

12.1 Format of the Command PA

15	8	7	0	
P		A		0 Name
Low word length				2 Length
High word length				4 Length
reserved		reserved		6 Sender
reserved		reserved		8 Receiver
TAG 1				
...				
...				
TAG n				
Check sum				Check sum

The total length of the PA Command is limited to maximum **2048** bytes. If the parameters to be loaded exceed this limit, then they must be distributed over several PA Commands. The individual tags may be distributed arbitrarily over several PA Commands, but tags are indivisible, i.e. any tag must be completely contained in one PA Command.

12.2 Format of the Response pa

The **pa** response has no specific data (see 1.4.2. General statement on responses).

12.3 PA Tags and Parameter (TAG-IDs)

Set camera to capture reference data images

TAG-ID TAG_SHC_SELECTION (91B H)

Format: SHORT

Data: 1st word: selection of SHC data
 Values: 0 = capturing no SHC data image
 1 = black level keep setting scan condition
 2 = black level without scan condition (static)
 3 = white level SHC keep setting scan condition
 4 = white level SHC without scan condition (static)

Default: 0

Note

With this TAG the camera board is initialized to capture an image for calculating shading reference data. Several parameters are set to specific values depending on the selected mode (refer tables below). After the shading procedure it is necessary to reload the setting to come back to the common scan condition.

This Tag can be sent within normal operation without any effect and is activated after receiving the “DE Command”.

Value 1..4			
Tag		Value	Hint
TAG_USE_COLOR_CONVERSION	0x22c	false	No color conversion
TAG_SET_GAMMAVALUE	0x229	10	No gamma correction
TAG_MIRROR_DATA_HOR	0x246	false	No mirror
TAG_USE_IP_FILTER_HOR	0x316	false	No filter
TAG_VIDEOLEVEL_CORRECTION	0x315	0	No dimming of brightness and contrast
TAG_SET_INSERTMODE	0x293	0	No Insert mode
TAG_SHOW_WHITE_REF_BORDERS	0x226	0	Disable display of white reference window
TAG_USE_KEYSTONECORRECTION	0x2b8	0	Disable display keystone correction (camera release P1.40 and higher)

Value 1 Black level with current setting scan condition			
Tag		Value	Hint
TAG_USE_BLACKLEVEL_CORRECTION	0x22b	false	Disable offset correction
TAG_USE_SHADING_CORRECTION	0x22a	false	Disable shading correction
TAG_USE_LINEARISATION_TABLE	0x397	false	No linearisation table
TAG_USE_WHITECONTROL	0x200	false	Disable white control because light should be off (camera release P1.40 and higher)

Value 2 Black level without current setting scan condition			
Tag		Value	Hint
TAG_USE_SCANCONDITION	0x236	false	Disable scan condition
TAG_USE_BLACKLEVEL_CORRECTION	0x22b	false	Disable offset correction
TAG_USE_SHADING_CORRECTION	0x22a	false	Disable shading correction
TAG_USE_LINEARISATION_TABLE	0x397	false	No linearization table
TAG_USE_WHITECONTROL	0x200	false	Disable white control because light should be off (camera release P1.40 and higher)

Value 3 White level SHC with current setting scan condition			
Tag		Value	Hint
TAG_USE_SHADING_CORRECTION	0x22a	false	Disable shading correction
TAG_USE_BLACKLEVEL_CORRECTION	0x22b	true	Use offset correction

Value 4 White level SHC without current setting scan condition			
Tag		Value	Hint
TAG_USE_SHADING_CORRECTION	0x22a	false	Disable shading correction
TAG_USE_SCANCONDITION	0x236	false	Disable scan condition
TAG_USE_BLACKLEVEL_CORRECTION	0x22b	true	Use offset correction

13. PK: Configuration Test

The configuration of the device is enquired with the Command PK. The response contains information on board hardware and versions of loaded software and load ware.

13.1 Format of the Command PK

If PK Command has no specific data (see General Statement on Commands) all TAGs defined below are responded.

The content of same specific TAGs can requested with sending the TAG ID in the first data field (see at the bottom of this paragraph).

13.2 Format of the Response pk

15	8	7	0	
p		k		0 Name
Low word length				2 Length
High word length				4 Length
Reserved		Reserved		6 Sender
Reserved		Reserved		8 Receiver
TAG1				10 see below
...				...
TAG n				
Check sum				Check sum

The tags of the pk response are container tags. They contain different kind of information from the camera.

Most of the TAG values sent with command MK to the camera are responded to Order PK

Definition of the Container TAGs for the Configuration Message

Container for configuration of the camera board

TAG-ID: TAG_KA4_2_KONFIG = 201 H (allPixa)
 Format: CONT
 Data: Tags for the configuration of the camera

Values: TAG_BETRIEBSZUSTAND (103 H)
 TAG_KONF_FIRMWARE (107 H)
 TAG_KONF_PROGRAM_TEXT (109 H), optional
 TAG_KONF_HW (210 H)
 TAG_KONF_LOGIC_KA4 (211 H)
 TAG_HSI_LEVEL (213 H)
 TAG_CONF_HW2 (214)
 TAG_LOGIC_DESCR_TEXT (255 H), optional
 TAG_GET_USED_SETTINGS (257 H)

Container for setting information

Additional to the parameters which are part of the internal setting the following information is responded to command PK.

TAG-ID: TAG_KA4_2_SETTING = 209 H (setting of allPixa)
 Format: CONT
 Data: Tags for detailed information of the camera board settings

Values: additional to TAG's defined in Command MK the following TAG's are received with

response pk:

TAG_ACTUAL_WHITE_REFERENCE (1C3 H)
 TAG_ERROR (1CA H)
 TAG_STATUS (1CB H)
 TAG_SENSOR_TYPE (212H)
 TAG_STATE_EXT_INPUT (245 H)
 TAG_COMMENT_LOADED_FILTER (249 H)
 TAG_SET_CAMERA_DESCRIPTION_TEXT (264 H) (see order "MK")
 TAG_GET_MININTTIME (274 H)
 TAG_GET_ACTIVE_CHANNELS (277 H)
 TAG_GET_EXTERNAL_SIGNALS_A (392 H)
 TAG_GET_FIRST_ACTIVE_PIXEL (394 H)
 TAG_GET_LAST_ACTIVE_PIXEL (395 H)
 TAG_GET_MAXIMUM_TRANSPORT_SPEED (396 H)
 TAG_LINEARIZATION_TABLE_DESCRIPTION (398 H)

Camera Operating state (input for container tag)

TAG-ID: TAG_BETRIEBSZUSTAND = 103 H
 Format: SHORT
 Data: 1st word: Operating state
 Values: 0 H: Device is defective
 1 H: Device is ready
 2 H: Device is warming up
 3 H: (reserved)
 4 H: (reserved)

Firmware configuration of a PCB-board (input for container tag)

TAG-ID: TAG_KONF_FIRMWARE = 107 H
 Format: VAR
 Data: 1st word: Program version of the firmware
 2nd word: Build of the firmware
 3rd word: type of the firmware (optional, depends upon the board)
 Values: 1st word - 2nd word: 0 H - FFFF H (16 bit unsigned)
 3rd word: Type
 0: Released program
 1: Special program
 2: Test program
 3: Locked program, only for development

Optional text for information about a program, firmware, or software (input for container tag)

TAG-ID: TAG_KONF_PROGRAM_TEXT = 109 H
 Format: VAR
 Data: up to 20 words: Additional text for information about a program
 (up to 40 byte, ASCII characters).
 Values: ASCII characters:
 Value range: 20 H - 7F H (96 character classes)

Note
 The text in the data words is entered as a character string.

Actual values of the white level reference (input for container tag)

TAG-ID: TAG_ACTUAL_WHITE_REFERENCE = 1C3 H
 Format: VAR

Data: 1st word: Red odd gain value
 2nd word: Red even gain value
 3rd word: Green odd gain value
 4th word: Green even gain value
 5th word: Blue odd gain value
 6th word: Blue even gain value
 7th word: Rear red odd gain value
 8th word: Rear red even gain value
 9th word: Rear green odd gain value
 10th word: Rear green even gain value
 11th word: Rear blue odd gain value
 12th word: Rear blue even gain value

Error status for the camera electronics (input for container tag)

TAG-ID: TAG_ERROR = 1CA H
 Format: SHORT

Data: 0 H – FFFF H (16 bit unsigned)

Status for the camera electronics (input for container tag)

TAG-ID: TAG_STATUS = 1CB H
 Format: Word

Data: Internal control states

Values: Bit 0-3: main control
 Bit 4-7: gain control

 Bit 12-15: disable white control reason

Hardware configuration of board (obsolete format)

TAG-ID: TAG_KONF_HW = 210 H
 Format: SHORT

Data: Version of board

Values: Bit 0-3: hardware revision board (DZ)
 Bit 4-7: Version of Lattice - HW
 Bit 8-11: type of hardware (allPixa = 7)

Loadware configuration of a camera board (input for container tag)

TAG-ID: TAG_KONF_LOGIC_KA4 = 211 H
 Format: SHORT

Data: Version of Xilinx load data
 Values: 0000 H – FFFF H

Supported Sensor Type

TAG-ID: TAG_SENSOR_TYPE = 212 H
 Format: VAR

Bit	15	0	
	Sensor-Id		Word 0
	Byte 1	Byte 0	Data
	Byte 39	Byte 38	Word 20

Sensor-Id: 0000 H - FFFF H
 Data: Sensor description, up to 40 byte, ASCII characters, End of string is marked with 0
 Values: ASCII characters:
 Value range: 20 H - 7F H (96 character classes)

Note

The text in the data words is entered as a character string.

HSI – Level

TAG-ID: TAG_HSI_LEVEL = 213 H
 Format: SHORT

Data:

Values: Bit 0-7: minor level
 Bit 8-15: major level

Shows the supported HSI-Level corresponding to HSI description document

Usually the major level is increased if new functionality is supported and the minor level at small changes in functionality.

Hardware configuration of boards

TAG-ID: TAG_CONF_HW2 = 214 H
 Format: VAR

Data: Versions

Values: Byte 0: version of board
 Byte 1: type of camera (allPixa=7)
 Byte 2: Version of Lattice - HW
 Byte 3: Version of aux board

Status of external inputs used for scan condition

TAG-ID: TAG_STATE_EXT_INPUT = 245 H
 Format: SHORT

Data:

- bit 0: shows level of LB0 signal
- bit 1: shows level of LB1 signal
- bit 2: shows level of LBS2 signal
- bit 3: shows level of LBS3 signal

- bit 4: signal toggles on any edge of LB0 signal
- bit 5: signal toggles on any edge of LB1 signal
- bit 6: signal toggles on any edge of LB2 signal
- bit 7: signal toggles on any edge of LB3 signal

(camera release P1.42 and higher)

- bit 4: signal toggles on every rising edge of LB0 signal
- bit 5: signal toggles on every rising edge of LB1 signal
- bit 6: signal toggles on every rising edge of LB2 signal

bit 7:	signal toggles on every rising edge of LB3 signal
bit 8:	shows level of encoder input signal Incr0
bit 9:	shows level of encoder input signal Incr1
Bit 12:	signal toggles on every valid edge of Incr0 signal
Bit 13:	signal toggles on any edge of Inkr0 or Incr1 signal

Note:

LBx and IncrX are logical IO function and must be mapped to specific input in the IO configuration matrix.

Description of loaded filter table

TAG-ID:	TAG_COMMENT_LOADED_FILTER (249H)
Format:	VAR
Data:	16 characters description text
Default:	“No filter loaded”

Time per pixel

TAG-ID:	TAG_GET_TIME_PERPIXEL = 253 H
Format:	SHORT
Data:	Time per pixel in resolution of 10 ps
Values:	0

The time per pixel is a hardware constant which depends from loaded FPGA design.

Description text for logic data, optional description text for FPGA version (input for container tag)

Tag-ID:	TAG_LOGIC_DESCR_TEXT (255 H)
Format:	VAR
Data:	30 characters version text

Used Settings

TAG-ID:	TAG_GET_USED_SETTINGS (257 H)
Format:	LONG
Data:	A ‘1’ in the setting corresponded bit position indicates that the stetting should be stored with ATS Function “Save all settings”.

If for example the data value is 6 then Setting No 1 and Setting No 2 is stored in the camera.

This TAG returns values which are set with setting specific TAG: TAG_MARK_SETTING_FOR_STORE (258H)

Minimal possible integration time for used sensor

TAG-ID:	TAG_GET_MININTTIME = 274 H
Format:	SHORT
Data:	Minimal Integration time in pixel units divided by 16

Shows active Channels

TAG-ID:	TAG_GET_ACTIVE_CHANNELS = 277 H
Format:	SHORT

Data: bit 0: Channel 0 is used
 bit 1: Channel 1 is used
 bit 2: Channel 2 is used
 bit 3: Channel 3 is used
 bit 4: Channel 4 is used
 bit 5: Channel 5 is used
 bit 6: Channel 6 is used
 bit 7: Channel 7 is used
 bit 8: Channel 8 is used
 bit 9: Channel 9 is used
 bit 10: Channel 10 is used
 bit 11: Channel 11 is used

Status of additional external inputs

TAG-ID: TAG_GET_EXTERNAL_SIGNALS_A (392 H)
Format: SHORT

First useable Pixel

TAG-ID: TAG_GET_FIRST_ACTIVE_PIXEL (394 H)
Format: SHORT

Data: Count of first usable Pixel

This value includes necessary time delays for reading the CCD in pixels counts.

Last useable Pixel

TAG-ID: TAG_GET_LAST_ACTIVE_PIXEL (395 H)
Format: SHORT

Data: Count of last usable Pixel

This value includes necessary time delays for reading the CCD in pixels counts.

Maximum speed

TAG-ID: TAG_GET_MAXIMUM_TRANSPORT_SPEED (396 H)
Format: SHORT

Data: maximum speed in mm/s

This TAG returns the maximum possible speed for a given vertical resolution.

If supported in TAG_SET_CCD_PARAMETER (260 H), speed is calculated from parameter MinIntegrationtime otherwise data given by TAG_SET_INTEGRATIONTIME_IN_NS (24A H) is used as base.

Description Linearising Table

TAG-ID: TAG_LINEARIZATION_TABLE_DESCRIPTION (398 H)

Format: VAR

Data: 16 characters description text

Default: “No table load”

13.3 List of Tags which are specific to request

TAG_SET_CAMERA_DESCRIPTION_TEXT (264 H)
TAG_SET_PRIVATE_DATA (266 H)

(see order MK)
(see order MK)

14. RS: Request State

Request state of camera

14.1 Format of the Command RS

The **RS** Command has no specific data.

14.2 Format of the Response rs

15	8	7	0	
r		s		0 Name
Low word length				2 Length
High word length				4 Length
Reserved		reserved		6 Sender
Reserved		Reserved		8 Receiver
Reserved		camera state		10 see below
Check sum				12 Check sum

camera state:

KA_STAT_POWER_ON	0
KA_STAT_IDLE	1
KA_STAT_DOWNLOAD	2
KA_STAT_SCAN_IDLE	3
KA_STAT_READY_FOR_SCAN	4
KA_STAT_SCANNING	5
KA_STAT_POWER_SAVE	6

If an internal error occurred command RS is responded with error message "fe".

15. DD: Download Digital Filters

With order DD digital filters are downloaded to camera and stored in non-volatile memory.

15.1 Format of the Command DD

15	8	7	0	
D		D		0 Name
Length low word				2 Length
High word length				4 Length
Reserved		reserved		6 Sender
Reserved		reserved		8 Receiver
FBGKENN				10 see below
TOD		TCD		12 Data, see below
FIKENN (low word)				14 see below
FIKENN (high word)				16 see below
MAG_NR (8 words)				18 see below
...				
Version				34
DATA FIELD (see below)				
Check sum				Check sum

FBGKENN = xxxx H: Board identifier (2 ASCII characters)
 = 'K1' Camera board KA1
 = 'K2' Camera board KA2
 = 'K3' Camera board KA3
 = 'K4' Camera board KA4

TCD = xx H: Bit depth of Data
 0 H: 10 bit Data

TOD = xx H: Type of Data

FIKENN = xx xxH Filter number (not necessary to use)

MAG_NR = 16 bytes: A short textual description of the filter to be loaded (ASCII string);

VERSION = xxxx H Current version of this structure is 2

DATA FIELD:

Command contains only Gamma correction tables

GAMMA_TABLE red channel	0
GAMMA_TABLE green channel	1024
GAMMA_TABLE blue channel	2048

GAMMA_TABLES:

The gamma tables for the color channels have 1024 entries with a width from one byte per entry. The first value in the Table sets the output for the input value 00 and so far.

TOD = 01: Command contains Gamma correction tables and a color conversion table

GAMMA_TABLE red channel	0
GAMMA_TABLE green channel	1024
GAMMA_TABLE blue channel	2084
COLOR TABLE (262144 words) (this table is optional) ... or Color Matrix Data	

TOD= 03: Special format to load gamma tables at first initialization.
 Start with word 32 follow 25 1k Tables with gamma values 0.1 – 2.5.
 These tables are selectable with TAG_SET_GAMMAVALUE.

GAMMA_TABLE for select value = 1	0
....	1024
GAMMA_TABLE for select value = 25	24576

TOD = 14: Color Conversion Matrix

Offset Red	36
Offset Green	38
Offset Blue	40
C00int	42
C01int	44
C02int	46
C10int	48
C11int	50
C21int	52
C22int	54
C23int	56

COLOR_MATRIX:

Contains Offset Correction Data and a 10 bit 3 x 3 Color Conversion Matrix

$$\begin{pmatrix} R_{out} \\ G_{out} \\ B_{out} \end{pmatrix} = \begin{pmatrix} C00, C01, C02 \\ C10, C11, C12 \\ C20, C21, C22 \end{pmatrix} * (R_{in} + Offset_R, G_{in} + Offset_G, B_{in} + Offset_B)$$

Offset Values: - 255 ... 255 take effect in 10 bit video range

Cxxint -511 ... 511

$$Cxxint = Round (Cxx * 256)$$

Parameters are used if TAG_USE_COLOR_LUT is true.

TOD =15: Input Linearization Table

Linearization table red odd channel	0
Linearization table green odd channel	1024
Linearization table blue odd channel	2048
Linearization table red even channel	3072
Linearization table green even channel	4096
Linearization table blue even channel	5120

Even tables are optional; if not available odd tables are used for odd and even channels.

Offset Red	36
Offset Green	38
Offset Blue	40
C00int	42
C01int	44
C02int	46
C10int	48
C11int	50
C21int	52
C22int	54
C23int	56

15.2 Format of the Response dd

The **dd** response has no specific data (see General Statement on Responses (see 1.4.2)).

16. DS: Download Reference data

The DS Command is used to load white or black level reference data in the camera board. This reference data is stored in non volatile RAM.

With the black level reference data the KAx board corrects the offset failure; with the white reference data the camera board corrects the shading effect.

This command is useful to load external calculated reference data in opposite to the Command MR which take reference data directly.

Up to four sets of reference data for black- and white level can be stored.

Maximum number of reference data: 10800 reference values

Format of the Command DS

15		8		70
D		S		0 Name
Low word length				2 Length
High word length				4 Length
Reserved		Reserved		6 Sender
Reserved		Reserved		8 Receiver
reserved				10 see below
Version				12 see below
RefNo		ArtRef		14 see below
PositionFirstRefPixel				16 see below
CorrectionLength				18 see below
Reserved				20 see below
Dummy Data (14 Words black level reference data at version 1) (20 Words white level reference data at version 1) With version = 3 no dummy data is used.				22 see below
Reference data ...				
...				
Check sum				

Version = 1 or 3 H Current Version of Header

ArtRef = 0 black level reference data
= 1 white level reference data

RefNo = 0 ... 3 Number of Dataset

Number of useable references depends on the revision of the camera

PositionFirstRefPixel = = 0000 H (obsolete)

CorrectionLength = xxxx H
Length of the given reference in number of pixel

Reserved must be to set 00H

Dummydata = xxxxH common to set 00H

Format of the Response ds

The **ds** response has no specific data (see 1.4.2)

17. DV: Download External IO Configuration Data

Format of the Command DV

15		8		70
	D		V	
	Low word length			0 Name
	High word length			2 Length
	Reserved			4 Length
	Reserved		Reserved	6 Sender
	Reserved		Reserved	8 Receiver
	Reserved			10 see below
	Version			12 see below
	Reserved1			14 see below
	Reserved2			16 see below
	Reserved 3			18 see below
	Reserved 4			20 see below
	Configuration Data in ASCII... (see below)			22
	Check sum			7998 (max) 8000 (max)

Version = 0 Current version of order

Reserved = recommend to set to 0

Configuration Data in ASCII:

Configuration is stored in CSV format with semicolon separated data columns. The rows are separated by a "0x0D0A" sequence. After last row the sequence "0x0D0A" must follow.

Line No	
1	Head Line
2	Author and Creation date
3	Field description
4	
...	IO-Description fields see below

IO-Description fields

Field No	field content	Format	Max No signs	Example
1	external function name	ASCII-Text	20	Frame impulse
2	External pin name	ASCII-Text	5	X3 P2
3	internal signal name	ASCII-Text	10	CL_CC3
4	Board specific io pin	ASCII-Text	5	X10 Pin 1
5	Signal level	ASCII-Text	5	LVTTL
6	Internal Function name	ASCII-Text	10	LS0
7	Select	0 1 ASCII Sign	1	1
8	link to function	a ... z A ... Z	2	A0
9	Bit no	ASCII chairs	2	
10	Register name	ASCII chairs	16	SelectEncoder

Select is set by TAG_SET_ EXTERNAL_SIGNAL_ASSIGNMENT.

Format of the Response dv

The dv response has no specific data (see 1.4.2)

18. UV: Upload External IO Configuration Data

The command UV read back data programmed with order DV to the camera.

The **UV** Command has no specific data.

Format of the Response uv

15	8	7	0	
u		v		0 Name
Low word length				2 Length
High word length				4 Length
Reserved		Reserved		6 Sender
Reserved		Reserved		8 Receiver
reserved				10 see below
Version				12 see below
Reserved1				14 see below
Reserved2				16 see below
Reserved 3				18 see below
Reserved 4				20 see below
Configuration Data in ASCII				22
Check sum				7998 (max) 8000 (max)

If no configuration data is available a uv response without specific data is returned. (see 1.4.2)

19. Appendix